

# **INTERFACE CONTROL DOCUMENT for the COMMON IMAGE GENERATOR INTERFACE (CIGI)**

Version 2.1: 28 January 2003



Report Number: TST02I015

W. B. Phelps

*Copyright © 2001-2003 The Boeing Company  
All rights reserved*

*Consult notes on the next page for copying and redistribution authority.  
PO Box 516, St. Louis, MO 63166 Phone (314) 232-8888 Fax (314) 232 2187 e-mail willard.b.phelps@boeing.com*

**LIST OF PAGES**

Title Page  
ii through viii  
1 through 108

**USE AND DISCLOSURE OF DATA**

This document is free; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

“You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.”

This document is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser Public License for more details.

This document is intended to be a public domain document. As such it does not contain any proprietary notices. The Boeing Company may make improvements and changes to the contents of this document at any time without notice. The Boeing Company assumes no responsibility for the use of the information in this document. This document may contain technical inaccuracies or typographical errors. Periodic changes are made to the information contained herein: these changes will be incorporated in new editions of the document. To maintain configuration control of the interface it is requested that this document not be reproduced in part for the purpose of modification to the interface. Please forward all modification suggestions to the maintainer shown at the bottom of the cover page for discussion and possible incorporation into the interface.

## TABLE OF CONTENTS

| <u>Paragraph</u>   | <u>Page</u> |
|--|-------------|
| <b>1. SCOPE.....</b>   | <b>1</b>    |
| 1.1 PURPOSE .....  | 1           |
| 1.2 INSTRUCTIONS FOR REVISING THIS DOCUMENT.....               | 1           |
| 1.3 INTRODUCATION.....   | 1           |
| <b>2. INTERFACE THEORY.....</b>                                | <b>3</b>    |
| 2.1 MESSAGE PROTOCOL.....                                      | 3           |
| 2.1.1 <i>Ethernet Message Synchronization</i> .....            | 3           |
| 2.1.2 <i>Ethernet Message Frequency</i> .....                  | 5           |
| 2.2 STARTUP SEQUENCE.....                                      | 5           |
| 2.3 EXTENDING THE INTERFACE.....                               | 5           |
| 2.4 DATA PACKAGING.....  | 6           |
| 2.4.1 <i>Message Structure</i> .....                           | 6           |
| 2.4.2 <i>Number Formats</i> .....                              | 8           |
| 2.4.2.1 Floating-Point Format .....                            | 8           |
| 2.4.2.2 Fixed-Point Format .....                               | 8           |
| <b>3. BASIC DEFINITIONS, PRINCIPLES AND NOMENCLATURE .....</b> | <b>9</b>    |
| 3.1 DEFINITION DATA PACKETS.....                               | 9           |
| 3.2 CONTROL DATA PACKETS.....                                  | 9           |
| 3.3 REQUEST DATA PACKETS.....                                  | 9           |
| 3.4 RESPONSE DATA PACKETS.....                                 | 9           |
| 3.5 ENTITIES.....  | 10          |
| 3.6 VIEWS .....  | 11          |
| <b>4. COORDINATE SYSTEMS .....</b>                             | <b>12</b>   |
| 4.1 ENTITY POSITIONING.....                                    | 12          |
| 4.2 ENTITY ORIENTATION.....                                    | 13          |
| 4.3 ENTITY COORDINATE SYSTEMS.....                             | 14          |
| <b>5. DATA PACKET NOMENCLATURE .....</b>                       | <b>15</b>   |
| 5.1 DATA PACKET RELATIONSHIPS.....                             | 15          |
| 5.2 DATA PACKET DESCRIPTION.....                               | 16          |
| 5.3 HOST-TO-IG PACKETS.....                                    | 17          |
| 5.3.1 <i>IG Control</i> .....                                  | 17          |
| 5.3.2 <i>Entity Control</i> .....                              | 19          |
| 5.3.3 <i>Component Control</i> .....                           | 28          |
| 5.3.4 <i>Articulated Part Control</i> .....                    | 34          |
| 5.3.5 <i>Rate Control</i> .....                                | 39          |
| 5.3.6 <i>Environment Control</i> .....                         | 43          |
| 5.3.7 <i>Weather Control</i> .....                             | 46          |
| 5.3.8 <i>View Control</i> .....                                | 50          |
| 5.3.9 <i>Sensor Control</i> .....                              | 55          |
| 5.3.10 <i>Trajectory Definition</i> .....                      | 59          |
| 5.3.11 <i>Special Effect Definition</i> .....                  | 61          |
| 5.3.12 <i>View Definition</i> .....                            | 65          |
| 5.3.13 <i>Collision Detection Segment Definition</i> .....     | 71          |
| 5.3.14 <i>Collision Detection Volume Definition</i> .....      | 75          |
| 5.3.15 <i>Height Above Terrain Request</i> .....               | 78          |
| 5.3.16 <i>Line of Sight Occult Request</i> .....               | 80          |
| 5.3.17 <i>Line of Sight Range Request</i> .....                | 83          |
| 5.3.18 <i>Height of Terrain Request</i> .....                  | 86          |

---

|           |   |            |
|-----------|---|------------|
| 5.4       | IG-TO-HOST PACKETS.....                           | 88         |
| 5.4.1     | <i>Start of Frame</i> .....                       | 88         |
| 5.4.2     | <i>Height Above Terrain Response</i> .....        | 91         |
| 5.4.3     | <i>Line of Sight Response</i> .....               | 93         |
| 5.4.4     | <i>Collision Detection Segment Response</i> ..... | 95         |
| 5.4.5     | <i>Sensor Response</i> .....                      | 97         |
| 5.4.6     | <i>Height of Terrain Response</i> .....           | 100        |
| 5.4.7     | <i>Collision Detection Volume Response</i> .....  | 102        |
| 5.4.8     | <i>Image Generator Message</i> .....              | 104        |
| 5.5       | USER-DEFINED DATA PACKETS.....                    | 105        |
| <b>6.</b> | <b>STATUS MESSAGES .....</b>                      | <b>107</b> |
| <b>7.</b> | <b>ACRONYMS .....</b>                             | <b>108</b> |

**LIST OF FIGURES**

| <u>Figure</u>   | <u>Page</u> |
|---|-------------|
| FIGURE 1 – DATA INTERFACE CONNECTIONS .....                               | 2           |
| FIGURE 2 – CIGI START OF FRAME/RESPONSE CYCLE .....                       | 4           |
| FIGURE 3 – MESSAGE TIMING OFFSET .....                                    | 4           |
| FIGURE 4 – ENTITY DEFINITIONS .....                                       | 10          |
| FIGURE 5 – VIEW MANIPULATION .....  | 11          |
| FIGURE 6 – ENTITY POSITION IN GEODETIC LATITUDE AND LONGITUDE.....        | 12          |
| FIGURE 7 – ENTITY ROTATION .....  | 13          |
| FIGURE 8 – ORDER OF ROTATION .....  | 13          |
| FIGURE 9 – ENTITY COORDINATE SYSTEM .....                                 | 14          |
| FIGURE 10 – DATA PACKET RELATIONSHIP NOMENCLATURE .....                   | 15          |
| FIGURE 11 – EXAMPLE OF DATA PACKET PARAMETER DIAGRAM.....                 | 16          |
| FIGURE 12 – EXAMPLE OF DATA PACKET NARRATIVE .....                        | 16          |
| FIGURE 13 – CREATION OF SINGLE ENTITY .....                               | 21          |
| FIGURE 14 – CREATION OF PARENT AND CHILD .....                            | 21          |
| FIGURE 15 – CREATION OF PARENT AND CHILD HIERARCHY .....                  | 22          |
| FIGURE 16 – EXAMPLES OF COMPONENT CONTROL APPLICATION .....               | 31          |
| FIGURE 17 – ARTICULATED PART CONTROL COMPONENTS .....                     | 34          |
| FIGURE 18 – ARTICULATED PART SUBMODEL COORDINATE SYSTEM .....             | 35          |
| FIGURE 19 – RATE CONTROL COMPONENTS .....                                 | 39          |
| FIGURE 20 – CLOUD ELEVATION AND THICKNESS.....                            | 46          |
| FIGURE 21 – VIEW POINT OFFSET AND ORIENTATION FROM ENTITY REFERENCE ..... | 50          |
| FIGURE 22 – SENSOR DEFINITION COMPONENTS .....                            | 55          |
| FIGURE 23 – TRAJECTORY DEFINITION COMPONENTS .....                        | 59          |
| FIGURE 24 – VIEW DEFINITION NOMENCLATURE.....                             | 65          |
| FIGURE 25 – INDIVIDUAL DEFINITIONS FOR THREE VIEWS .....                  | 66          |
| FIGURE 26 – A GROUP OF THREE INDIVIDUAL VIEWS .....                       | 66          |
| FIGURE 27 – VIEW SEPARATED FROM A VIEW GROUP .....                        | 66          |
| FIGURE 28 – COLLISION DETECTION SEGMENT DEFINITION.....                   | 71          |
| FIGURE 29 – COLLISION VOLUME DEFINITION.....                              | 75          |
| FIGURE 30 – GATE OFFSET AND SIZE .....                                    | 97          |

**LIST OF TABLES**

| <u>Tables</u>  | <u>Page</u> |
|--|-------------|
| TABLE 1 – DATA PACKET SUMMARY.....                         | 6           |
| TABLE 2 – EXAMPLE SEQUENCE OF HOST-TO-IG MESSAGES .....    | 7           |
| TABLE 3 – ENTITY/EFFECT ANIMATION STATE ACTION TABLE ..... | 20          |
| TABLE 4 – COMPONENT IDENTIFICATION SCHEME.....             | 28          |
| TABLE 5 – CIGI STATUS MESSAGES .....                       | 107         |

| INDEX OF CHANGE PAGES |  |       |         |  |              |          |
|-----------------------|--|-------|---------|--|--------------|----------|
| Revision Letter       | Pages Affected                                 |       |         | Remarks  | Revised By   | Approval |
|                       | Revised  | Added | Removed |  |              |          |
| New                   |  |       |         |  |              |          |
| 1.0                   | all  |       |         | Serious updates  | W. B. Phelps |          |
| 2.0                   | Cover pages                                    |       |         | Added note for copying and redistribution authority  | W. B. Phelps |          |
|                       | 1, 2   |       |         | Re-write of introduction material  | W. B. Phelps |          |
|                       | 3, 4   |       |         | Re-write of interface theory material  | W. B. Phelps |          |
|                       | 5, 98, 99                                      |       |         | Added User definable data packets  | W. B. Phelps |          |
|                       | 5,6  |       |         | Added new packet titles to data packet identification table  | W. B. Phelps |          |
|                       | 8, 10  |       |         | Added Basic Definitions, Principles and Nomenclature section   | W. B. Phelps |          |
|                       | 15   |       |         | Updated data packet description section  | W. B. Phelps |          |
|                       | 16, 82   |       |         | Changed version number to 2  | W. B. Phelps |          |
|                       | 16, 17   |       |         | Added timing value to IG Control data packet   | W. B. Phelps |          |
|                       | 18, 19   |       |         | Re-wrote Entity Control data packet narrative  | W. B. Phelps |          |
|                       | 21, 25, 72, 73, 74, 75, 77, 78, 85, 86, 87, 88 |       |         | Changed all altitudes to double float values and adjusted packet padding accordingly   | W. B. Phelps |          |
|                       | 21, 24   |       |         | Added Percent Transparency to Entity Control data packet   | W. B. Phelps |          |
|                       | 21, 22, 24                                     |       |         | Redefined Entity state and effects state switches in the Entity Control data packet  | W. B. Phelps |          |
|                       | 27, 28, 29                                     |       |         | Added examples of various uses of Component controls   | W. B. Phelps |          |
|                       | 30, 31   |       |         | Added Sensor ID to the Component Control data packet.  | W. B. Phelps |          |
|                       | 33, 34, 35, 36                                 |       |         | Changed Articulated Parts offset and rotational values from fixed point to floating point values   | W. B. Phelps |          |
|                       | 41, 42, 43                                     |       |         | Introduce MODTRAN into the Environmental Control data packet   | W. B. Phelps |          |
|                       | 44   |       |         | Added diagram to Weather Control data packet narrative   | W. B. Phelps |          |
|                       | 55, 56   |       |         | Removed Offsets in Trajectory definition data packet already accommodated in the Entity Control data packet.   | W. B. Phelps |          |
|                       | 65, 66, 67                                     |       |         | Renamed Collision Detection Definition to Collision Detection Segment Definition to distinguish it from Swept Volume technique and clarified narrative | W. B. Phelps |          |
|                       | 65, 67   |       |         | Redefined Material Mask to Collision Mask  | W. B. Phelps |          |
|                       | 69, 70, 71                                     |       |         | Added Swept Volume Collision Detection Definition data packet  | W. B. Phelps |          |
|                       | 74, 75, 76                                     |       |         | Added clarification for the LOS occult request   | W. B. Phelps |          |
|                       | 80, 81   |       |         | Added HOT request data packet.   | W. B. Phelps |          |
|                       | 82, 84   |       |         | Added timing value to Start of Frame data packet   | W. B. Phelps |          |
|                       | 89, 90   |       |         | Renamed Collision Detection Response to Collision Detection Segment Response to distinguish it from Swept Volume technique                             | W. B. Phelps |          |
|                       | 93, 94   |       |         | Added HOT response data packet   | W. B. Phelps |          |
|                       | 95, 96   |       |         | Added Swept Volume Collision Detection Response data packet  | W. B. Phelps |          |
|                       | 97   |       |         | Added Image Generator Response Message data packet   | W. B. Phelps |          |
|                       | Many   |       |         | Corrected grammatical errors   | W. B. Phelps |          |
| 2.1                   | Many   |       |         | Corrected grammatical, spelling, punctuation, and capitalization errors  | L. Durham    |          |
|                       | Many   |       |         | Made minor changes to parameter names (non-trivial name changes are notated where applicable)  | L. Durham    |          |
|                       | Many   |       |         | Changed default parameter values to "N/A" where no default value is applicable   | L. Durham    |          |

|            |  |           |
|------------|--|-----------|
| Cover      | Changed Revision Number, Date, and Copyright Notice  | L. Durham |
| 1          | Updated Scope to obsolete version 2.0 of this document   | L. Durham |
| 3          | Revised Section 2.1.1 to indicate a distinction between Start of Frame packets and Start of Frame messages   | L. Durham |
| 4          | Changed Figure 3 Caption   | L. Durham |
| 5          | Changed name of IG mode from "Standby (reset)" to "Standby/Reset"  | L. Durham |
| 6          | Reworded Section 2.4.1 to address superfluous packets containing unchanged data (this text was removed from individual packet descriptions); Updated Table 1                     | L. Durham |
| 7          | Revised and updated Table 2  | L. Durham |
| 8          | Added "Number Formats" super heading (subsequent section numbers changed accordingly); Revised description of Scaled Distance Format; Removed section pertaining to Angle Format | L. Durham |
| 12 – 13    | Revised text to distinguish between top-level and child entities   | L. Durham |
| 16, others | Added names of those parameters marked by an asterisk (*) below the packet diagram   | L. Durham |
| 17         | Added "Host-to-IG Packets" super heading (subsequent section numbers changed accordingly); Increased valid range for Database Number parameter from 99 to 127                    | L. Durham |
| 18         | Renamed IG Mode Change Request enumerated value from "standby (reset)" to "Standby/Reset;" Changed Timing Value parameter's unit from "usec" to "µsec"                           | L. Durham |
| 20         | Reworded text relating to the use of the Opacity parameter; Added text to address Opacity and Temperature for weather phenomena  | L. Durham |
| 21         | Renamed Figures 13 and 14  | L. Durham |
| 22         | Dropped "Entity" from position and orientation parameter names   | L. Durham |
| 25         | Corrected Percent Opacity parameter's valid range to indicate the correct range as 0.0 – 100.0   | L. Durham |
| 28         | Revised packet description for clarity; Revised Table 4  | L. Durham |
| 34         | Added text describing submodelcoordinate systems   | L. Durham |
| 35         | Added Figure 18; Revised text for clarity; Renamed Articulated Part Heading parameter to "Yaw"   | L. Durham |
| 36         | Reordered parameter definitions to reflect the order of the fields within the packet; Revised descriptions of enumerated values for State parameter                              | L. Durham |
| 40 – 42    | Renamed $V_x$ Component of the Velocity Vector parameter to "X Linear Rate" (ditto for Y and Z components); Renamed "Heading Angular Rate" parameter to "Yaw Angular Rate"       | L. Durham |
| 43         | Renamed Wind Velocity parameter to "Wind Speed"  | L. Durham |
| 44         | Revised descriptions of enumerated values for Ephemeris Enable parameter   | L. Durham |
| 45         | Renamed Wind Velocity parameter to "Wind Speed"  | L. Durham |
| 46         | Revised packet description; Renamed Winds Aloft Velocity parameter to "Winds Aloft Speed"  | L. Durham |
| 47         | Revised Entity ID parameter description for clarity; Renamed Scud parameter to "Scud Frequency"  | L. Durham |

|         |  |  |           |
|---------|--|--|-----------|
| 48      |  | Revised Air Temperature and Opacity parameter descriptions to address weather entities   | L. Durham |
| 49      |  | Revised valid values for Elevation parameter to include negative values (below Mean Sea Level); Changed MSL to Mean Sea Level  | L. Durham |
| 50      |  | Revised packet description for clarity   | L. Durham |
| 51 – 54 |  | Renamed Enable/Disable View Heading parameter to "Yaw Enable;" Renamed View Heading parameter to "Yaw"   | L. Durham |
| 52      |  | Updated View Group Select value descriptions   | L. Durham |
| 58      |  | Corrected Gain parameter's valid range to indicate the correct range as 0.0 – 1.0  | L. Durham |
| 61 – 63 |  | Renamed Red Color Value parameter to "Red Component" (ditto for Green and Blue); Renamed Burst Rate parameter to "Burst Interval;" Renamed Burst Count parameter to "Effect Count"   | L. Durham |
| 66      |  | Revised text   | L. Durham |
| 68      |  | Revised descriptions of enumerated values for Pixel Replication parameter  | L. Durham |
| 69 – 70 |  | Changed Field of View parameter defaults to indicate they should be set by the IG configuration; Corrected valid ranges of values for those parameters   | L. Durham |
| 71      |  | Revised packet description text for clarity and to address missed collisions   | L. Durham |
| 72      |  | Reordered parameter definitions to reflect the order of the fields within the packet   | L. Durham |
| 73      |  | Corrected Collision Mask parameter's data type and revised description   | L. Durham |
| 75      |  | Renamed packet from "Swept Volume Collision Detection Definition" to "Collision Detection Volume Definition;" Revised packet description for clarity and to address missed collisions  | L. Durham |
| 76      |  | Reordered parameter definitions to reflect the order of the fields within the packet   | L. Durham |
| 83 – 85 |  | Renamed LOS Request Heading parameter to "Azimuth;" Renamed LOS Request Pitch parameter to "Elevation;" Renamed LOS Request Minimum Distance parameter to "Minimum Range;" Renamed LOS Request Maximum Distance parameter to "Maximum Range" | L. Durham |
| 88      |  | Added "IG-to-Host Packets" super heading (subsequent section numbers changed accordingly); Increased valid range for Database Number parameter from +99 to +127  | L. Durham |
| 90      |  | Changed Timing Value parameter's units from "usec" to "µsec"   | L. Durham |
| 95      |  | Revised text for clarity   | L. Durham |
| 102     |  | Renamed packet from "Swept Volume Collision Detection Response" to "Collision Detection Volume Response;" Revised text for clarity   | L. Durham |
| 104     |  | Renamed packet from "Image Generator Response Message" to "Image Generator Message"  | L. Durham |
| 105     |  | Renamed packet from "User-Definable Data Packet" to "User-Defined Data Packet"   | L. Durham |
| 108     |  | Revised Acronyms   | L. Durham |



## 1. Scope

This document describes Version 2 of the open-source Common Image Generator Interface (CIGI). This document supersedes Version 2.0 of the CIGI Interface Control Document.

This document does not contain any proprietary notices as this interface is intended for unrestricted public use.

### 1.1 Purpose

This Interface Control Document (ICD) is to be used by software engineers to aid in the integration of an image generator (IG) with a Host Simulator using the Common Image Generator Interface (CIGI). This document contains a description of all data parameters, event sequences, and Input/Output (I/O) protocols necessary to accomplish this task.

This interface is meant to be generic in nature and provide a Host simulator the capability to communicate with an image generator equipped with the CIGI. As such, typical IG control functions are provided, but unique control functions are absent. A generic control (i.e. Component Control) is provided for unique functions such that given a mapping of the specific controls or functions to the generic control, the integration engineer has all the information necessary to program these functions. This document should be accompanied by a control function definition document for these unique controls. That document should contain the function identification and parameter value assignments pertinent to a given control function. A majority of these functions may have default values programmed on the IG that are sufficient as defined and may never require alteration by the host.

The CIGI provides controls to manage entities by type designation. In order to complete the integration of the host with the IG, the type assignment needs to be defined. In addition, specific terrain features and terrain sets may have controls and IDs that must be known. These identifications should be captured in a database definition document. That document should contain parameter value assignments and peculiarities pertinent to a given database and the entities, moving or stationary, used with it.

### 1.2 Instructions for Revising this Document

For version correlation purposes this interface has the CIGI version number in the IG Control and Start of Frame data packets. This means that any time a change is made to this document that affects data formatting the designated version number in these blocks must be incremented.

This version number will always correspond to the major version number of the appropriate CIGI Interface Control Document. A change in the minor revision number of the ICD will indicate that corrections or enhancements have been made to the document, but not to the message structures or data formats themselves.

### 1.3 Introduction

The Host simulator discussed herein, also referred to as the “Host,” communicates with the IG via a bi-directional Ethernet connection. The data contained in these communications consists of information to perform data synchronization and mission scenarios. The data are formatted per the CIGI protocol. Each of these data and their associated formats are contained within the CIGI will be explained and discussed in this document.

The CIGI is a data packaging protocol. To date it has been implemented using an Ethernet medium. That is not to say that the CIGI is limited to Ethernet applications. The communication medium can be whatever is appropriate for the situation: an optical interface, mirrored memory, shared memory, etc. The following description assumes the use of Ethernet for ease of discussion. It should not be difficult for implementers to imagine how the CIGI would be implemented using other communication media. As with any formally configured application, the version of the communications medium must be established among the users. Because of the additional overhead of TCP, UDP is the recommended protocol for Ethernet implementations of CIGI.

The Ethernet connection between the Host and the IG should be a dedicated Ethernet connection, as illustrated in Figure 1. The connection may be made using a single crossover Ethernet cable (i.e. were the transmit and receive signals are swapped so that an Ethernet hub or switch is not required) or via an Ethernet hub or switch. The IP address and send and receive ports for each device are configurable.




Figure 1 – Data Interface Connections

## 2. Interface Theory

### 2.1 Message Protocol

#### 2.1.1 Ethernet Message Synchronization

CIGI supports both synchronous and asynchronous operation. Synchronous operation is the preferred mode because it provides an interface with the least amount of latency or message delay and avoids cumbersome interpolation or extrapolation computations. Asynchronous operation is accommodated by placing timing values in the mandatory Start of Frame and IG Control data packets to allow for definition of the data timing methods.

Asynchronous operation demands that the positional and attitude data provided from a Host be corrected to compensate for disparities of when the data was derived in the Host to when the data is to be used in the IG. In synchronous operation this is not necessary as the IG video frame and data creation in the Host is “locked” via a sync operation. In an asynchronous operation the compensation for the disparity between when data is derived and the time it is used is typically done using an interpolation or extrapolation process. Because there are many interpolation and extrapolation mechanisms available the particular implementation will not be discussed here. There are several pieces of information that are needed for the interpolation or extrapolation mechanisms. First there is a time factor. This time factor is provided for in the CIGI by the timing values in the mandatory Start of Frame and IG Control data packets. It is intended that the IG will compute any necessary frame-to-frame time deltas using this information. Depending on the fidelity required for the simulation either velocity (rate) or acceleration information may be used to derive position and attitude information within the IG. Velocity (rate) information can be provided from the Host simulation via the Rate Control data packet described in section 5.3.5. As of this writing the CIGI does not implement a data packet containing acceleration information, however a user-defined data packet as described in Section 5.5 may be used to implement such a packet. The remainder of this section discusses the CIGI’s synchronization mechanism.

During synchronous operation, the IG begins each frame by transmitting a message via Ethernet to the Host. This message is referred to as the “Start of Frame Message” and must always begin with a Start of Frame data packet (section 5.4.1). This start of frame produces a “heartbeat” which dictates the timing of data transfers between the IG and the Host. Any other data packets destined for the Host may follow the Start of Frame data packet in the Ethernet message.

The Host should immediately respond to the Start of Frame Message with an Ethernet message containing as its first data packet an IG Control data packet (section 5.3.1). Other data packets destined for the image generator may follow the IG Control data packet in the Ethernet message. Because of the timing of the interface, these data will represent the state of the simulation during the previous frame. When the IG receives this response, it can then begin performing its computational and rendering cycles. Meanwhile, the Host updates its simulation parameters such as entity states, atmospheric, mission function requests, etc., then waits for the next start of frame signal to transmit these new values to the image generator. Figure 2 illustrates this sequence:




Figure 2 – CIGI Start of Frame/Response Cycle

Depending on bandwidth limitations and the amount of Ethernet traffic on the system, the IG may not receive a response early enough to complete its computational cycle before the start of the next frame. To alleviate this situation, a time offset can be introduced to offset the Host and IG frame periods. Because the IG controls the start of the frame and the frame rate, the idea is to send a start of frame signal before the actual beginning of each IG frame. This mechanism will allow Host to IG data to arrive at such a time as to allow the IG its entire frame time for computations and rendering. Because the Ethernet bandwidth may vary from frame to frame, this offset can be adjusted to allow for worst-case network loads so that no late arrivals occur. Figure 3 illustrates the start of frame offset technique:




Figure 3 – Message Timing Offset

As a capability to track Ethernet messages, the data packets contained in the IG-to-Host and Host-to-IG Ethernet transfers are tagged with sequence numbers. The sequence number originates within the IG and is passed to the Host in the IG-to-Host Frame Counter parameter of the Start of Frame data packet. The Host should extract this number from the Start of Frame data packet and place it into the Host to IG Frame Counter parameter of the IG Control data packet that is returned from the Host. In this way, Ethernet communications can be checked for one-to-one correspondence.

### 2.1.2 Ethernet Message Frequency

The IG software can be configured to run at any reasonable frequency. Typically, the IG data update rate should match the display refresh rate to alleviate stepping and other undesirable effects caused by asynchronous data updates. This means that for synchronous operation, the Host must also be bound to a multiple of the display update rate or must extrapolate its data each frame to meet the specified IG update rate. Common update rates are 30 and 60 Hz.

## 2.2 Startup Sequence

The Host should only communicate with the IG in response to a Start of Frame message. Upon initial power-up the IG may wait a predetermined amount of time before communicating with the Host to allow the display system and other components to initialize. It is recommended that this time be configurable within the IG. The IG should be considered mission-ready when it sends its first start of frame signal. Normal communications should proceed from this point. If the host attempts to manipulate mission data before this time, the IG will not process the data and the information will be lost.

The IG will be set to the Standby/Reset mode of operation after completion of the startup cycle. The Host is sent the first start of frame signal at this juncture. The IG will remain in this mode until it encounters a change in the IG Mode parameter of the IG Control data packet contained within a Host response message. The Host must change the IG operational mode to *operate* and wait for the mode change to be acknowledged in the IG Mode parameter of the Start of Frame data packet before attempting to send initialization or mission data to the IG.

Upon power-up, the IG may pre-load a default database or test pattern as specified in the IG configuration. If another database is desired, the Host can request that database once the IG is mission-ready. Because the IG must be reinitialized during a database load, data relating to previous operations will be lost and should be re-instantiated by the Host, as necessary. See the Database Number parameters of the IG Control and Start of Frame data packets in sections 5.3.1 and 5.4.1 for further details.

After completion of operational training sessions, the Host should command the CIGI back to the Standby/Reset mode. This is done so that all entities that were instantiated during the previous training session are removed from the display before a new training session begins.

To use the IG maintenance mode, the Host must first command the IG to the Standby/Reset mode via the IG Mode parameter of the IG Control data packet described in section 5.3.

## 2.3 Extending the Interface

Although the CIGI is a robust interface, there may be times when a developer wishes to define a unique data packet format for a specific purpose. For this reason, CIGI has been designed to be extensible. Data packet opcodes 236 through 255 have been reserved for user-defined data packets.

Note that when an implementation uses one or more user-defined packets, that implementation is no longer strictly CIGI-compliant. Developers should be aware that any host or IG device that uses such extensions may not work with other CIGI devices without significant integration effort.

Refer to Section 5.5 of this document for further details on user-defined data packets.

## 2.4 Data Packaging

### 2.4.1 Message Structure

CIGI messages are comprised of one or more data packets. The first byte of each packet contains an opcode that uniquely identifies the packet type. The second byte of each packet contains the size in bytes of the packet. The remainder of each packet contains data that pertain to that particular packet. Refer to section 5.2 for general packet formatting information, or to sections 5.3.1 – 5.5 for information on specific packets.

The message from the IG to the host must begin with a mandatory Start of Frame data packet (section 5.4.1). The message may also contain other IG-to-Host packets as listed in Table 1.

The response message from the host to the IG must begin with a mandatory IG Control packet (section 5.3.1). Zero or more Host-to-IG packets may follow within the message.

An entity must exist before it can have parameters or attributes applied to it. For example, if a Component Control is to be applied to an entity in the same message in which the entity is first specified (created), the Component Control data packet must follow the corresponding Entity Control data packet in the message. Other than these requirements, no restrictions are placed on packet ordering and all other data packets can move in relative position in the data buffer from frame to frame.

To reduce the risk of overloading the IG computational frame, an attempt should be made to minimize the amount of data contained in each message supplied to the IG. Therefore, unless a packet is mandatory (see Table 1), only those packets containing new data should be contained within each message. For example, if an entity's position, orientation, or other attributes have not changed since the previous frame, the host should not send an Entity Control packet.

**Table 1 – Data Packet Summary**

| Opcode            | Data Packet Name                       | Mandatory Every Frame | Section |
|-------------------|--|-----------------------|---------|
| <b>Host to IG</b> |  |                       |         |
| 1                 | IG Control                             | Yes                   | 5.3.1   |
| 2                 | Entity Control                         | No                    | 5.3.2   |
| 3                 | Component Control                      | No                    | 5.3.3   |
| 4                 | Articulated Part Control               | No                    | 5.3.4   |
| 5                 | Rate Control                           | No                    | 5.3.5   |
| 6                 | Environment Control                    | No                    | 5.3.6   |
| 7                 | Weather Control                        | No                    | 5.3.7   |
| 8                 | View Control                           | No                    | 5.3.8   |
| 9                 | Sensor Control                         | No                    | 5.3.9   |
| 21                | Trajectory Definition                  | No                    | 5.3.10  |
| 22                | Special Effect Definition              | No                    | 5.3.11  |
| 23                | View Definition                        | No                    | 5.3.12  |
| 24                | Collision Detection Segment Definition | No                    | 5.3.13  |
| 25                | Collision Detection Volume Definition  | No                    | 5.3.14  |
| 41                | Height Above Terrain Request           | No                    | 5.3.15  |
| 42                | Line of Sight Occult Request           | No                    | 5.3.16  |
| 43                | Line of Sight Range Request            | No                    | 5.3.17  |
| 44                | Height of Terrain Request              | No                    | 5.3.18  |
| <b>IG to Host</b> |  |                       |         |
| 101               | Start of Frame                         | Yes                   | 5.4.1   |
| 102               | Height Above Terrain Response          | No                    | 5.4.2   |
| 103               | Line of Sight Response                 | No                    | 5.4.3   |
| 104               | Collision Detection Segment Response   | No                    | 5.4.4   |

|                                  |                                     |                        |       |
|----------------------------------|-------------------------------------|------------------------|-------|
| 105                              | Sensor Response                     | See Packet Description | 5.4.5 |
| 106                              | Height of Terrain Response          | No                     | 5.4.6 |
| 107                              | Collision Detection Volume Response | No                     | 5.4.7 |
| 108                              | Image Generator Message             | No                     | 5.4.8 |
| <b>User Defined Data Packets</b> |                                     |                        |       |
| 236 – 255                        | User-Defined Data Packets           | Application-Dependent  | 5.5   |

During real-time operation, only a subset of these data packets are required in any given message to describe data changes to the IG. For example, Table 2 shows the data packet IDs of a hypothetical sequence of Host-to-IG messages. Note that each message begins with an IG Control message.

**Table 2 – Example Sequence of Host-to-IG Messages**

| Frame   | 1          | 2                                 | 3                                  | 4                                  | 5  | ... |
|---------|------------|-----------------------------------|------------------------------------|------------------------------------|--|-----|
| $n$     | IG Control | Entity Control<br>(Entity ID = 0) | Entity Control<br>(Entity ID = 5)  | Entity Control<br>(Entity ID = 91) | Special Effect<br>Definition<br>(Entity ID = 91) | ... |
| $n + 1$ | IG Control | Entity Control<br>(Entity ID = 0) | Entity Control<br>(Entity ID = 5)  | View Control                       |  |     |
| $n + 2$ | IG Control | Entity Control<br>(Entity ID = 0) | Entity Control<br>(Entity ID = 5)  |                                    |  |     |
| $n + 3$ | IG Control | Entity Control<br>(Entity ID = 0) | Entity Control<br>(Entity ID = 91) | View Control                       |  |     |
| $n + 4$ | IG Control | Entity Control<br>(Entity ID = 0) |                                    |                                    |  |     |
| $n + 5$ | IG Control | Entity Control<br>(Entity ID = 0) | Entity Control<br>(Entity ID = 5)  |                                    |  |     |
| $n + 6$ | IG Control | Entity Control<br>(Entity ID = 0) | View Control                       |                                    |  |     |
| $n + 7$ | IG Control | Entity Control<br>(Entity ID = 0) |                                    |                                    |  |     |

## 2.4.2 Number Formats

### 2.4.2.1 Floating-Point Format

Data represented as a floating-point number are formatted in single - or double-precision IEEE format.

### 2.4.2.2 Fixed-Point Format

Data represented as a fixed-point number are formatted as 16-bit fixed-point numbers as shown in the following diagram:

#### Scaled distance format (16 bit scaled at B6)

| Sign                  | $2^8$ | $2^7$ | $2^6$ | $2^5$ | $2^4$ | $2^3$ | $2^2$ | $2^1$                  | $2^0$ | $2^{-1}$ | $2^{-2}$ | $2^{-3}$ | $2^{-4}$ | $2^{-5}$ | $2^{-6}$ |
|-----------------------|-------|-------|-------|-------|-------|-------|-------|------------------------|-------|----------|----------|----------|----------|----------|----------|
| 15                    | 14    | 13    | 12    | 11    | 10    | 9     | 8     | 7                      | 6     | 5        | 4        | 3        | 2        | 1        | 0        |
| Most significant byte |       |       |       |       |       |       |       | Least significant byte |       |          |          |          |          |          |          |

Format: 16-bit, two's complement, fixed-point B(9, -6)  
 Resolution:  $2^{-6}$   
 Range:  $-2^9$  through  $2^9 - 2^{-6}$  (-512.0 through 511.984375)



### 3. Basic Definitions, Principles and Nomenclature

The following section will describe some commonly used definitions, nomenclature and basic principles that are used when discussing the CIGI.

#### 3.1 Definition Data Packets

Definition data packets are used to define or alter the characteristics of a CIGI feature. There are definition packets for defining trajectories, special effects, views, collision detection segments and collision detection volumes. For instance the Trajectory Definition data packet can be used in conjunction with the Entity Control data packet, the Special Effects Definition data packet, and the Rate data packet to define aspects of an object's trajectory, such as a bullet's flight. The Special Effects Definition data packet can be used in conjunction with the Entity Control data packet to override the default-modeled parameters within an effect. View Definition data packets can be used to define the characteristics of a view and/or override the IG default configuration of a view. Collision Detection Segment Definition and Collision Detection Volume Definition data packets can be used to define collision structures that can be tested for intersections with other objects or surfaces within the simulation environment. See their respective sections for detailed discussion on these definition data packets.

#### 3.2 Control Data Packets

Control data packets are used to control features within the IG. There are data packets for controlling the image generator, entities, components, articulated parts, entity rates, environmental parameters, weather parameters, views, and sensors. For example, the IG Control data packet contains information that controls, among other things, the IG states, database selection, frame count, and data timing values. Entity Control data packets control the physical parameters of an object in the simulation scenario such as its appearance, temperature, transparency characteristics, and its position and attitude. The Component Control data packet is provided as a generic control mechanism to manipulate components contained within the synthetic environment or an entity. It is used to control the aspect of components such as light intensities, symbology placement, polygon and texture component states, etc. The Articulated Part Control data packet contains parameters to control parts that can articulate such as flaps, slats, speed brakes, etc. The Articulated Part Control data packet can be used to move such parts in up to six degrees of freedom. The Rate Control data packet can be used to specify the rate parameters of an entity or supplement other packets' information, such as the Trajectory Definition data packet. Atmospheric phenomena are controlled using the Environmental and Weather Control data packets. With these packets, the user can control global environment parameters and override default local or layered weather phenomena. View Control data packets are used to control the position and orientation of a view that has either been previously defined in the IG or has been defined by a View Definition data packet. For detailed discussions on these data packets see their respective sections.

#### 3.3 Request Data Packets

Request data packets are used to make requests of the image generator. There are data packets for requesting the height above terrain, height of terrain, line of sight occulting and line of sight ranging information. The Height Above Terrain data packet will invoke a response from the image generator that contains information about the height above the terrain for a specific point specified in the request. The Height of Terrain data packet will invoke a response from the image generator that contains information about the height of the terrain at a specified location. The Line of Sight Occult data packet is used to determine intervisibility or occulting between a source and destination point. The Line of Sight Range data packet is used to determine the range from a source point to an object within the environment. For detailed discussions on these request data packets see their respective sections.

#### 3.4 Response Data Packets


Response data packets are sent from the image generator to the Host in response to a request data packet. There are response data packets that correspond to each type of request data packet discussed above, plus a

sensor response data packet. The details of the use of these data packets can be seen in their respective sections of this document.

### 3.5 Entities

Within the CIGI, an entity is defined as an object that has a separate and distinct instance within the synthetic environment. Entity types can include stationary and repositionable objects. Some examples are vehicles such as aircraft, ships and ground vehicles; special effects such as explosions, missile trails, and smoke; ground features such as buildings, towers, and bridges; or attributes such as lights and steerable lobes.

A unique instance of an Entity is identified by its Entity ID. An Entity ID is merely a way to identify a single dynamic coordinate system. Any object known to the CIGI can be assigned to an Entity ID by its Entity Type. In this way, the user can instantiate up to several instances of the same object by assigning the same Entity Type to several unique Entity IDs. This principle can be seen in the missiles and missile trails in Figure 4. The number assignments in this example are hypothetical.



**Figure 4 – Entity Definitions**

Entities can also be attached to one another. Attached entities are said to have a parent/child relationship. The depth of the parent/child chain is only limited by the computational capabilities of the Host and IG platforms. In Figure 4, the missiles and missile trails could be maneuvered in one of two ways. First, each missile and missile trail could be driven uniquely, requiring the host to provide position and attitude data for each of the four entities. The simpler and typically preferred way would be to establish a parent/child

relationship between each missile and missile trail pair. This would be done by establishing Entity ID 4 (missile trail) as a child of the Entity ID 2 (missile), and likewise for Entity IDs 5 and 3. When entities are parented, the host is only obligated to control the top-level parent entity via the CIGI. All children will be “chained” to the parent within the image generator, and no unique manipulation of a child entity is necessary unless its position and attitude change with respect to its parent. For more details on parenting entities, see section 5.3.2.

### 3.6 Views

Views are used to create the viewing portals for a display system. The display system can be of any variety, such as an Out-the-Window visual system, a sensor channel display, a Night Vision Goggle scope, etc. Views can be defined in size and depth and can be positioned and rotated. Views can also be grouped together to create contiguous panoramic views. Views can be attached to entities such as the Ownship, or attached to a weapon’s seeker to provide a sensor view. Figure 5 gives an idea of how views can be manipulated. See the View Control and View Definition data packet descriptions in sections 5.3.8 and 5.3.12 for a detailed discussion on view manipulation.




Figure 5 – View Manipulation

## 4. Coordinate Systems

### 4.1 Entity Positioning

CIGI specifies a top-level (non-child) entity's position in Geodetic Coordinates. The Geodetic Coordinate system specifies a location as a latitude, longitude, and altitude. The altitude is the distance from a point in space to the closest point on the Earth's ellipsoidal surface. This altitude line will be perpendicular to the flat plane that is tangent to the earth at this point. Altitude is measured positive above the surface of the reference ellipsoid, and negative below it. As this line is extended toward the polar axis (Z-axis) it intersects the equatorial plane, giving the latitude angle,  $lat$ , as shown in Figure 6, measured positive north of the equator and negative south, limited to  $\pm 90^\circ$ . The altitude line then intersects the Z-axis to give the longitude angle,  $lon$ , measured positive east of the Prime Meridian and negative west, limited to  $\pm 180^\circ$ .






Figure 6 – Entity Position in Geodetic Latitude and Longitude

**4.2 Entity Orientation**

The orientation of a top-level (non-child) entity is specified with respect to a plane tangent to the ground at a point directly beneath it. The entity coordinate system is parallel with the Local North, East, Down coordinate system when the entity's Heading, Pitch, and Roll are all zero. Figure 7 illustrates the entity coordinate system. The order of rotation is defined in CIGI to be about the Z, Y and then X axes (i.e. heading, pitch, and then roll), as seen in Figure 8.



**Figure 7 – Entity Rotation**



**Figure 8 – Order of Rotation**

### 4.3 Entity Coordinate Systems

For convenience, a typical aircraft reference system is used to describe the coordinate axis used for an entity, as shown in Figure 9, with +X out through the nose, +Y out the starboard side, and +Z through the ventral side.





Figure 9 – Entity Coordinate System

## 5. Data Packet Nomenclature

### 5.1 Data Packet Relationships


The CIGI uses a principle of base objects and redefinition theory. That is to say objects, including entities, special effects and views, are defined based on a unique identification for each instance. An entity, including special effects, is created via the Entity Control data packet. A View is created via the View Control data packet. The creation of an entity or view establishes its base definition. After these entities or views are established they can be modified via other data packets. A diagram showing some of the possible relationships between data packets accompanies the description of each data packet described as necessary. The nomenclature used in these diagrams is explained in Figure 10.



**Figure 10 – Data Packet Relationship Nomenclature**

**5.2 Data Packet Description**

Each data packet format is discussed in the following sub-paragraphs. The parameter assignments for each data packet are shown in a diagram similar to the one in Figure 11. All CIGI packets use big-endian byte ordering.



\*1 Parameters marked with an asterisk (\*) followed by a number denote that the space in the parameter diagram is not large enough to contain the parameter name. The name will be listed immediately below the table.

**Figure 11 – Example of Data Packet Parameter Diagram**

A narrative description of each datum is presented in a section below the data packet diagram as seen in the example in Figure 12.

| Formats and Ranges   | Description   |
|--|---|
| Packet ID = 1  | This area identifies the data packet.<br>This area also identifies any restrictions on the usage of the data packet.  |
| Name : Type : Units<br>Valid Values:<br>Default: N/A<br>Datum: | This area identifies the data parameter’s name, type and any applicable units. It also identifies any restrictions on the values of a data parameter and the default value, if any, that the IG will assign the parameter until a data packet containing that parameter is sent to the IG. The datum for a parameter, such as Mean Sea Level for altitude will also be provided, if appropriate.<br><br>This area will also provide a narrative of the intended use for the data parameter and how it may interact with other parameters in the Ethernet message. |

**Figure 12 – Example of Data Packet Narrative**



**5.3 Host-to-IG Packets**

**5.3.1 IG Control**

The IG Control data packet is contained in the Ethernet message sent from the Host to the IG. This data packet is mandatory in each Ethernet message and is used to control various operations of the IG. Because the IG Control data packet may contain information that will determine how other data in the Ethernet message will be used, it shall be the first data packet in the Host to IG Ethernet data buffer. If this rule is not followed, an error will be returned to the Host and no further action will be taken for that frame.

The contents of the IG Control data packet are shown below.

|                          |    |    |       |    |    |    |    |                        |    |    |    |    |    |    |    |                         |    |    |    |                 |    |   |   |   |   |   |   |   |   |   |   |
|--------------------------|----|----|-------|----|----|----|----|------------------------|----|----|----|----|----|----|----|-------------------------|----|----|----|-----------------|----|---|---|---|---|---|---|---|---|---|---|
| 31                       | 30 | 29 | 28    | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15                      | 14 | 13 | 12 | 11              | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 1            |    |    |       |    |    |    |    | Packet Size = 16 bytes |    |    |    |    |    |    |    | CIGI Version Number = 2 |    |    |    | Database Number |    |   |   |   |   |   |   |   |   |   |   |
| *1                       | *2 | *3 | Spare |    |    |    |    |                        |    |    |    |    |    |    |    |                         |    |    |    |                 |    |   |   |   |   |   |   |   |   |   |   |
| Host to IG Frame Counter |    |    |       |    |    |    |    |                        |    |    |    |    |    |    |    |                         |    |    |    |                 |    |   |   |   |   |   |   |   |   |   |   |
| Timing Value             |    |    |       |    |    |    |    |                        |    |    |    |    |    |    |    |                         |    |    |    |                 |    |   |   |   |   |   |   |   |   |   |   |

- \*1 IG Mode
- \*2 Tracking Device Enable
- \*3 Tracking Device Boresight

**IG Control Parameter Definitions:**

| Formats and Ranges  | Description   |
|---|---|
| Packet ID = 1 : unsigned char : N/A   | This parameter identifies this data packet as the IG Control data packet.<br><br>There can be only one instance of this data packet per frame. If more than one data packet is received the last one received will be used.   |
| Packet Size : unsigned char : N/A   | This parameter indicates the number of bytes in this data packet.   |
| CIGI Version Number : unsigned char : N/A<br><br>Valid Values:<br><br>0 – 255<br><br>Default: N/A   | This parameter indicates the version of the CIGI interface that is currently running on the host. The image generator can use this number to determine concurrency.   |
| Database Number : signed char : N/A<br><br>Valid Values:<br><br>-128 to -1 Not used<br>0 No load requested<br>1 to 127 Request load of this database<br><br>See the Database Number table in the applicable Database and Entity Attribute Definition Document(s).<br>Default: N/A | This parameter indicates the number associated with the database requiring loading. Placing a valid database number in this field will cause the IG to commence loading of the requested database. The IG will respond with the negated value of the database number that is requested indicating that the database load is under way. This indication is provided in the Database Number data field of the Start of Frame data packet, section 5.4.1. When the Host receives this indication, it should return this parameter to zero. This must be done to prevent the IG from loading the database again upon completion of the previously requested load. Also, during the time that the IG is returning the negated value, mission data will be ignored. Therefore the Host should not send any data packets to the IG other than the IG Control data packet during a database load. |

|  |  |
|--|--|
| <p>IG Mode Change Request : 2 bit field : N/A</p> <p>Valid Values:</p> <p>0 = Standby/Reset<br/>1 = Operate<br/>2 = Debug</p> <p>Default: 0</p>          | <p>This parameter is used by the Host to command the IG to enter its various modes. When the IG receives a request for a mode change via this parameter it will return the corresponding mode in the Current IG Mode parameter of the Start of Frame data packet once the mode change has been accomplished.</p> <p><i>Standby/Reset</i> – See the discussion on the Standby/Reset mode in the Current IG Mode parameter description in the Start of Frame data packet in section 5.4.1.</p> <p><i>Operate</i> – See the discussion on the operate mode in the Current IG Mode parameter description in the Start of Frame data packet in section 5.4.1.</p> <p><i>Debug</i> – See the discussion on the debug mode in the Current IG Mode parameter description in the Start of Frame data packet in section 5.4.1.</p> |
| <p>Tracking Device Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable Tracking Inputs<br/>1 = Enable Tracking Inputs</p> <p>Default: N/A</p> | <p>This parameter is used by the Host to enable or disable an external tracking device connected to the image generator. An example would be a head tracker used to drive head position. Currently only one tracking device is supported by this interface</p>   |
| <p>Tracking Device Boresight : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = No Action<br/>1 = Boresight</p> <p>Default: N/A</p>                         | <p>This parameter is used by the Host to enable the boresight mode (zeroing out of view offset positions and angles) for an external tracking device connected to the image generator.</p> <p>Boresight mode will be active while this parameter is set to 1 (Boresight).</p>  |
| <p>Frame Counter : unsigned integer : N/A</p> <p>Valid Values:</p> <p>0 to 4,294,967,295</p> <p>Default: N/A</p>   | <p>This parameter contains a number representing a particular frame. The Host should copy the corresponding value from the IG to Host Frame Counter parameter in the Start of Frame data packet, section 5.4.1 and place it in this parameter to show that this Host Ethernet message is in response to a particular IG Ethernet message.</p>  |
| <p>Timing Value : Float IEEE: <math>\mu</math>sec</p> <p>Valid Values:</p> <p>0 to 86,399,999,999.99</p> <p>Default: N/A</p>                             | <p>This parameter is optional for synchronous operation, but required for asynchronous operation. It contains a timing value that is used to time-tag the Ethernet message when asynchronous operation is instituted. When asynchronous operation is used, the synchronous timing scheme described in section 2.1.1 is superseded.</p> <p>In order to preserve floating-point accuracy, this timing value is limited to a 24-hour simulation period. At the end of 24 hours, the counter will reset to zero.</p>   |

### 5.3.2 Entity Control

The Entity Control data packet is contained in the Ethernet message sent from the Host to the IG. An entity is defined as an object that has a separate and distinct instance within the synthetic environment. Entity types can include moving or repositionable objects such as aircraft, ships, ground vehicles, special effects, ground models, lights, steerable lobes, etc. An entity can also be created that represents nothing more than a “camera” for the purpose of controlling a view.

The Entity Control data packet is used to instantiate an entity in one of two ways: 1) as a unique entity where this data packet is used to manipulate its attitude and geodetic position, and 2) as a child of a parent entity where this data packet is used to manipulate the child’s attitude and positional offset relative to its parent’s reference point. All positional data represent the position of the entity’s reference point, which corresponds to the model origin. This is typically, but not necessarily, the entity’s center of gravity.

This data packet applies to all entities that are required for the simulation, including the Ownship.

In order to reduce the load on Ethernet messages and the IG computational frame, only Entity Control data packets that contain data changes should be included in the Ethernet message. Once an Entity Control packet describing an entity is sent to the IG, the state of that entity will not change until another Entity Control packet containing that entity ID is received. For example, packets describing the Ownship and a wingman may be sent every frame to indicate continuous positional changes, while a packet describing an inactive SAM site may be sent once during mission initialization.

The Entity State field is used to control when an entity is visible and when its geometry is loaded and unloaded. When an entity is created, the Entity State field can be set to *Load/Show* to specify that the entity should be added to the scene as soon as the model geometry is loaded. The entity can then be temporarily removed from the scene graph, or made invisible, by setting Entity State to *Load/Hide*. When the entity is no longer needed, Entity State can be set to *Unload* to direct the IG to unload the geometry and free any memory allocated for the entity.

Models can also be preloaded to increase the speed at which they can be initially displayed. For example, when the Ownship fires a missile, a new entity would need to be created for that missile. Unless the missile geometry is cached, the IG must load the model from disk. Because of its tremendous speed, the missile might fly beyond visual range before the disk I/O can be completed. By preloading the entity, the geometry can already exist in memory and be instantly loaded into the scene graph when needed. To accomplish this, an Entity Control packet with the Entity State flag set to *Load/Hide* would be sent to the IG during mission initialization or at some other point prior to firing of the missile. When the missile is needed, another Entity Control packet for that entity would be sent containing the proper positional data and with the Entity State flag set to *Load/Show*.

Child entities inherit the entity state of their parent. In other words, the Entity State parameter of a parent entity affects not only that entity, but also all its children. When a parent’s Entity State parameter is set to *Load/Hide*, all the children will be hidden. Likewise, when a parent’s Entity State is set to *Load/Show*, all the children that have not been explicitly hidden will be shown. When a parent’s Entity State parameter is set to *Unload*, the entity and all its children will be destroyed by the IG.

The Effect Animation State field is used to control the animation state of entities representing special effects. When an effect is preloaded, the Effect Animation State parameter should be set to *Stop* and the effect will remain in its initial state. To start the animation sequence at any time thereafter, the host would send an Entity Control packet with its Entity State and Effect Animation State parameters to *Load/Show* and *Play*, respectively. Setting the Effect Animation State to *Stop* simply stops the animation sequence at the current frame. Setting the parameter to *Play* in a subsequent frame will resume the animation; setting it to *Restart* will play the animation from its initial state. If an effect is modeled as momentary (i.e., having limited duration), it will stop automatically. The host may reactivate a momentary effect by setting the Effect Animation State to *Restart* without having to first set the parameter to *Stop*.

Continuing the example above, if the missile were to hit an enemy aircraft, the aircraft would likely explode. During mission initialization, to preload the effect, the host would have first sent an Entity Control packet specifying the ID of the explosion and the Entity State (*Load/Hide*), and then an Effect Control packet describing the direction, size, and other attributes of the effect. During the exercise, if the missile were to hit its target, the host would set the Entity State for the missile's Entity Control packet to *Load/Hide* or *Unload*. The host would then send another Entity Control packet for the explosion. In this packet, the Entity State field would be set to *Load/Show* and the Effect Animation State field would be set to *Play* or *Restart*. After the explosion dissipates, the host could destroy the entity, or it could set Entity State to *Load/Hide* and reuse the explosion later.


Table 3 summarizes the actions possible with the Entity State and Effect Animation State fields.

**Table 3 – Entity/Effect Animation State Action Table**

| Entity Type | Action   | Entity State | Effect Animation State |
|-------------|--|--------------|------------------------|
| Non-effect  | Load but don't show  | Load/Hide    | –                      |
| Non-effect  | Load and show  | Load/Show    | –                      |
| Non-effect  | Show   | Load/Show    | –                      |
| Non-effect  | Hide   | Load/Hide    | –                      |
| Non-effect  | Hide and unload  | Unload       | –                      |
| Effect      | Load but don't play (preload); Stop and hide (if already loaded)   | Load/Hide    | Stop                   |
| Effect      | No action, effect is hidden  | Load/Hide    | Play                   |
| Effect      | No action, effect is hidden  | Load/Hide    | Restart                |
| Effect      | Pause  | Load/Show    | Stop                   |
| Effect      | Load and play from beginning; Play loaded effect (1 <sup>st</sup> time); Continue playing, or resume if paused | Load/Show    | Play                   |
| Effect      | Load and play from beginning; Play loaded effect (1 <sup>st</sup> time); Restart loaded effect from beginning  | Load/Show    | Restart                |
| Effect      | Stop and unload  | Unload       | Stop                   |
| Effect      | Unload   | Unload       | Play                   |
| Effect      | Unload   | Unload       | Restart                |


The alpha applied to an entity's geometry can be modified with the Percent Opacity parameter. This is expressed as a percentage, with 0% being transparent and 100% being fully opaque. The affect of a parent's opacity on a child is dictated by the child entity's type. For non-effect child entities, the opacity is inherited. In other words, the child's opacity is multiplied with its parent's opacity. The would allow, for example, a propeller model to fade in proportion to an airplane at the limits of the ownship pilot's visual range. For special effect child entities, the opacity is not inherited, and the child's alpha must be set independently.

Entities may be used to represent weather phenomena. If a Weather Control packet is used to specify weather-specific attributes for the entity, the Opacity and Temperature parameters of that packet are ignored. These attributes should instead be set using the Opacity and Temperature parameters of the Entity Control packet. Refer to Section 5.3.7 for more information.



The Entity Control data packet is used to establish the base object of an entity.

**Figure 13 – Creation of Single Entity**



The Entity Control data packet can be used to either uniquely identify an entity or establish a parent-child relationship between two or more entities. A child is uniquely identified by its Entity ID and is associated to a parent entity by its Parent ID. In this case an ejection seat entity is parented to an airframe entity.

**Figure 14 – Creation of Parent and Child**




Figure 15 – Creation of Parent and Child Hierarchy

The contents of the Entity Control data packet are shown below.

|                          |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    |                  |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|--------------------------|----|----|----|-------|----|----|----|------------------------|----|----|----|----|----|----|----|------------------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31                       | 30 | 29 | 28 | 27    | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15               | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 2            |    |    |    |       |    |    |    | Packet Size = 56 bytes |    |    |    |    |    |    |    | Entity ID        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| *1                       | *2 | *3 | *4 | Spare |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Entity Type              |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Percent Opacity          |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Internal Temperature     |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Roll                     |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Pitch                    |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Heading                  |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Altitude/Z Offset (MSW)  |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Altitude/Z Offset (LSW)  |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Latitude/X Offset (MSW)  |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Latitude/X Offset (LSW)  |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Longitude/Y Offset (MSW) |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Longitude/Y Offset (LSW) |    |    |    |       |    |    |    |                        |    |    |    |    |    |    |    | Parent Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

- \*1 Entity State
- \*2 Attach State
- \*3 Collision Detection Request
- \*4 Effect Animation State

## Entity Control Parameter Definitions:

| Formats and Ranges  | Description   |
|---|---|
| Packet ID = 2 : unsigned char : N/A   | <p>This parameter identifies this data packet as the Entity Control data packet.</p> <p>There can be multiple instances of this data packet per frame, but each unique entity should only be specified once per frame. If more than one data packet with the same Entity ID is received in the same frame, the last one received will be used.</p>  |
| Packet Size : unsigned char : N/A   | <p>This parameter indicates the number of bytes in this data packet.</p>  |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 = Ownship entity<br>1 to 65535<br><br>Default: N/A             | <p>This parameter indicates the entity motion system this data packet represents.</p> <p>If the specified entity id contains zero the parameters in this data packet will be applied to the Ownship. If the specified entity id contains a number greater than zero the parameters in this data packet will be applied to the specified entity.</p>   |
| Entity State : 2 bit field : N/A<br><br>Valid Values:<br><br>0 = Load/Hide<br>1 = Load/Show<br>2 = Unload<br><br>Default: N/A | <p>This parameter specifies whether an entity's geometry should be visible/invisible, or whether the entity should be destroyed.</p> <p>When an entity is required, this parameter should be set to <i>Load/Hide</i> or <i>Load/Show</i>. This will cause the IG to create a new instance of the type specified in the Entity Type parameter, and this new instance will initially be invisible or visible, respectively. Once the new entity's geometry has been loaded, changing this parameter sets the visibility of the geometry accordingly. When the entity is no longer required, this parameter should be set to <i>Unload</i> to remove the entity's hierarchy from the scene graph. Note that destroying an entity causes all child entities (attachments and special effects) to be destroyed, as well.</p> |

|   |   |
|---|---|
| <p>Attach State : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Detach<br/>1 = Attach</p> <p>Default: N/A</p>                 | <p>This parameter specifies whether the entity it represents should be attached as a child to a parent.</p> <p><b>To specify a unique (parent) entity, or to accomplish a detachment:</b></p> <ul style="list-style-type: none"> <li>- This parameter must be set to <i>Detach</i>.</li> <li>- The Entity State parameter must be set to <i>Load/Show</i> or <i>Load/Hide</i>.</li> <li>- The Entity ID parameter must be valid.</li> <li>- The positional information in this data packet should specify the entity's Latitude, Longitude, and Altitude.</li> </ul> <p>The Parent Entity ID parameter is ignored.</p> <p><b>To accomplish an attachment:</b></p> <ul style="list-style-type: none"> <li>- This parameter must be set to <i>Attach</i>.</li> <li>- The Entity State parameter must be set to <i>Load/Show</i> or <i>Load/Hide</i>.</li> <li>- The Entity ID parameter must be valid.</li> <li>- The Parent Entity ID parameter must be valid, i.e., the parent entity must be previously defined.</li> <li>- The positional information in this data packet should specify the X Offset, Y Offset, and Z Offset from the parent.</li> </ul> <p>Once the assignment is made, the IG will retain the parent-child relationship until the parent entity is destroyed or the child is detached from the parent.</p> |
| <p>Collision Detection Request : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p> | <p>This parameter enables or disables collision detection for this entity. See the Collision Detection Segment and Collision Detection Volume Response data packet descriptions in sections 5.4.4 and 5.4.7 for details about the return data.</p>  |



|  |   |
|--|---|
| <p>Effect Animation State : 2 bit field : N/A</p> <p>Valid Values:</p> <p>0 = Stop<br/>1 = Play<br/>2 = Restart</p> <p>Default: N/A</p>  | <p>This parameter specifies the animation state of a special effect. This parameter applies only when the value of the Entity Type parameter corresponds to an effect.</p> <p><i>Stop</i> – Stops the animation sequence. Has no effect if the animation is currently stopped.</p> <p><i>Play</i> – Begins playback from the current animation frame. If an animation was previously stopped mid-sequence, playback continues from that point. If an animation has not yet been played, or if it has been played through its entirety and stopped, playback begins at the start of the sequence.</p> <p><i>Restart</i> – Starts playback from the beginning of the animation sequence. Note that this value is a momentary state; leaving this parameter set to <i>Restart</i> in subsequent frames will cause playback to restart with each CIGI frame, making the effect appear to “hang” at its initial animation state.</p> |
| <p>Entity Type : unsigned short : N/A</p> <p>Valid Values:</p> <p>See the entity identification assignments in the applicable Database and Entity Attribute Definition Document(s).</p> <p>0 = Not visible</p> <p>Default: N/A</p> | <p>This parameter indicates the type for the entity being represented by this data packet. If the integration engineer wishes to attach a view to a position without a model present, a 0 can be used in this field to signify that no type be used. This will effectively cause the entity to not be shown in the visual scene.</p> <p>If the specified Entity Type is invalid, an error will be generated and the data packet will be disregarded.</p>  |
| <p>Parent Entity ID : unsigned short : N/A</p> <p>Valid Values:</p> <p>0 = Ownship entity<br/>1 to 65535</p> <p>Default: N/A</p>   | <p>This parameter indicates the parent to which this entity should be attached. This field is only valid when the Attach/Detach Switch is set to Attach.</p> <p>If the specified Parent Entity ID is not active, an error will be generated and the data packet will be disregarded.</p>  |
| <p>Percent Opacity : Float IEEE : N/A</p> <p>Valid Values:</p> <p>0.0 to 100.0 where:</p> <p>0.0 Entity is fully transparent<br/>100.0 Entity is fully visible</p> <p>Default: N/A</p>   | <p>This parameter specifies the degree of opacity of the Entity. A fully visible entity will have a Percent Opacity of 100.0 (no fade applied). A fully invisible entity will have a Percent Opacity of 0.0 (full fade applied).</p>  |

|   |  |
|---|--|
| <p>Internal Temperature : Float IEEE : degrees Celsius</p> <p>Valid Values:</p> <p>    Minimum to maximum allowed by the data format</p> <p>Default: N/A<br/>Datum: 0° C</p>  | <p>This parameter specifies the internal temperature of the Entity. It is used to show internal contrast such as engine warming on thermal views.</p>  |
| <p>Roll : Float IEEE : degrees</p> <p>Valid Values:</p> <p>    0 to +180 right wing down<br/>    0 to -180 left wing down</p> <p>Default: N/A<br/>Datum: See description at right.</p>  | <p>This parameter specifies the roll angle of the Entity.</p> <p>If the Attach/Detach Switch of this data packet is set to <i>Detach</i>, the Entity Roll is relative to the coordinate system shown in Figure 7.</p> <p>If the Attach/Detach Switch of this data packet is set to <i>Attach</i>, the Entity Roll is relative to the parent coordinate system shown in Figure 9.</p>   |
| <p>Pitch : Float IEEE : degrees</p> <p>Valid Values:</p> <p>    0 to +90 nose up<br/>    0 to -90 nose down</p> <p>Default: N/A<br/>Datum: See description at right.</p>  | <p>This parameter specifies the pitch of the Entity.</p> <p>If the Attach/Detach Switch of this data packet is set to <i>Detach</i> the Entity Pitch is relative to the coordinate system shown in Figure 7.</p> <p>If the Attach/Detach Switch of this data packet is set to <i>Attach</i>, the Entity Pitch is relative to the parent coordinate system shown in Figure 9.</p>       |
| <p>Heading : Float IEEE : degrees</p> <p>Valid Values:</p> <p>    0 to +360 clockwise</p> <p>Default: N/A<br/>Datum: See description at right.</p>  | <p>This parameter specifies the heading of the Entity.</p> <p>If the Attach/Detach Switch of this data packet is set to <i>Detach</i> the Entity Heading is relative to the coordinate system shown in Figure 7.</p> <p>If the Attach/Detach Switch of this data packet is set to <i>Attach</i>, the Entity Heading is relative to the parent coordinate system shown in Figure 9.</p> |
| <p>Altitude : Double IEEE : meters</p> <p>Valid Values:</p> <p>    Minimum to maximum allowed by the data format</p> <p>Default: N/A<br/>Datum: Mean Sea Level, See Figure 6.<br/>----- Or -----<br/>Z Offset: Double IEEE : meters</p> <p>Valid Values:</p> <p>    Minimum to maximum allowed by the data format</p> <p>Default: N/A<br/>Datum: Parent Reference Point</p> | <p>This parameter specifies the altitude position of the reference point of the Entity.</p> <p>This parameter specifies the Z Offset of a child entity's reference point from its parent's reference point.</p>  |

|   |  |
|---|--|
| Latitude : Double IEEE : degrees              | This parameter specifies the latitude position of the reference point of the Entity.                         |
| Valid Values:                                 |  |
| 0 to +90 (north positive)                     |  |
| 0 to -90 (south negative)                     |  |
| Default: N/A                                  |  |
| Datum: equator, See Figure 6.                 |  |
| ----- Or -----                                |  |
| X Offset: Double IEEE : meters                | This parameter specifies the X Offset of a child entity's reference point from its parent's reference point. |
| Valid Values:                                 |  |
| Minimum to maximum allowed by the data format |  |
| Default: N/A                                  |  |
| Datum: Parent Reference Point                 |  |
| Longitude : Double IEEE : degrees             | This parameter specifies the longitude position of the reference point of the Entity.                        |
| Valid Values:                                 |  |
| 0 to +180 (east positive)                     |  |
| 0 to -180 (west negative)                     |  |
| Default: N/A                                  |  |
| Datum: Prime Meridian, See Figure 6.          |  |
| ----- Or -----                                |  |
| Y Offset: Double IEEE : meters                | This parameter specifies the Y Offset of a child entity's reference point from its parent's reference point. |
| Valid Values:                                 |  |
| Minimum to maximum allowed by the data format |  |
| Default: N/A                                  |  |
| Datum: Parent Reference Point                 |  |

### 5.3.3 Component Control


The Component Control data packet is contained in the Ethernet message sent from the Host to the IG. The Component Control data packet is provided as a generic control mechanism to manipulate components contained within the synthetic environment. Components are identified by first specifying the particular class they belong to, then identifying the particular instance of the class, and then identifying the particular component within the instance. The IG and database will provide a configuration mechanism that maps components and controls to the appropriate Component Class, Instance ID and Component ID. Examples of these associations can be seen in Table 4.

This data packet contains both a discrete integer value and two continuous floating-point values. A component control may use any or all of these values. The following table shows an example of a discrete state manipulation where the entity F-16C can have air brake states of 25, 50, 75 and 100 percent open. The table also shows an example of a continuous value where the entity F-15C formation light's intensity can be selected from 0 to 100 percent. Another example of a continuous value is shown where a sensor gate symbol can be placed within the sensor display by using both floating-point values, one for X position and the other for Y position.


**Table 4 – Component Identification Scheme**

| Component Class | Instance ID     | Component ID  |
|-----------------|-----------------|---|
| Entity          | F-15C           | Anti-collision light on/off<br>Position lighting on/off<br>Formation lighting intensity, 0 to 100%<br>Air brake position partial open<br>Air brake position full open   |
| Entity          | F-16C           | Anti-collision light on/off<br>Position lighting on/off<br>Formation lighting intensity, 0 to 100%<br>Air brake position 25% open<br>Air brake position 50% open<br>Air brake position 75% open<br>Air brake position 100% open |
| Environment     | Sky             | Red color<br>Blue color<br>Green color<br>Sun on/off<br>Moon on/off   |
| Environment     | Haze            | Red color<br>Blue color<br>Green color  |
| Environment     | Terrain         | Runway centerline intensity, 0 to 100%<br>Runway edge light intensity, 0 to 100%<br>Runway threshold light intensity, 0 to 100%   |
| View            | View ID         | Zoom  |
| View Group      | View Group ID   | Zoom  |
| Sensor          | Sensor ID       | Gate Symbol Position  |
| Sensor          | Sensor ID       | Cursor Symbol Position  |
| System          | Image Generator | Screen blanking<br>(Crash indicator)  |


Example of a Component Control data packet controlling an entity related attribute:




Example of a Component Control data packet controlling terrain lights and haze color attributes:




Example of a Component Control data packet controlling a sensor related attribute:



The Component Control data packet can be used to control uniquely identified elements of a sensor. A unique component is identified by its Component ID and is associated to a unique sensor by the Sensor ID. In this case a symbol being moved within a display.



Example of a Component Control data packet controlling a View or View Group related attribute:



(It should be noted that a zooming feature may also be implemented using a View Definition data packet.)

**Figure 16 – Examples of Component Control Application**

The contents of the Component Control data packet are shown below.

|                 |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |                   |    |    |    |    |    |   |   |                   |   |   |   |   |   |   |   |
|-----------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|-------------------|----|----|----|----|----|---|---|-------------------|---|---|---|---|---|---|---|
| 31              | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15                | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7                 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 3   |    |    |    |    |    |    |    | Packet Size = 20 bytes |    |    |    |    |    |    |    | Instance ID       |    |    |    |    |    |   |   |                   |   |   |   |   |   |   |   |
| Component Class |    |    |    |    |    |    |    | Spare                  |    |    |    |    |    |    |    | Component State   |    |    |    |    |    |   |   |                   |   |   |   |   |   |   |   |
| Component ID    |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Component Value 1 |    |    |    |    |    |   |   | Component Value 2 |   |   |   |   |   |   |   |

Component Control Parameter Definitions:


| Formats and Ranges   | Description   |
|--|---|
| Packet ID = 3 : unsigned char : N/A  | This parameter identifies this data packet as the Component Control data packet.<br><br>There can be multiple instances of this data packet per frame. Component information for a unique component, can only be specified once per frame. If more than one is received per frame the last one received will be used.   |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.   |
| Instance ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A  | This parameter indicates the instance of a class the component being controlled belongs to. It is used in conjunction with the Component Class and Component ID to uniquely identify a component. The relationship between Component Class, Instance ID, and Component ID is explained in the narrative and Table 4 of this section.  |
| Component Class : unsigned char : N/A<br><br>Valid Values:<br><br>0 = Entity<br>1 = Environment<br>2 = View<br>3 = View group<br>4 = Sensor<br>5 = System<br><br>Default: N/A  | This parameter indicates what class the component being controlled is in. It is used in conjunction with the Instance ID and Component ID to uniquely identify a component. The relationship between Component Class, Instance ID, and Component ID is explained in the narrative and Table 4 of this section.  |
| Component ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to maximum allowed by the data format<br><br>See the Component Control assignments in the applicable Database, Entity Attribute, and IG functions Definition Document (s).<br><br>Default: N/A | This parameter identifies the Component of a Component Class and Instance ID this data packet will be applied to. It is used in conjunction with the Component Class and Instance ID to uniquely identify a component. The relationship between Component Class, Instance ID, and Component ID is explained in the narrative and Table 4 of this section.<br><br>If an invalid Component ID is specified, an error will be generated and the data packet will be disregarded. |



|   |   |
|---|---|
| <p>Component State : unsigned short : N/A</p> <p>Valid Values:</p> <p>0 to maximum allowed by the data format<br/>See the Component Control assignments in the applicable Database, Entity Attribute, and IG functions Definition Document (s).</p> <p>Default: N/A</p>       | <p>This parameter specifies the commanded state of a Component.</p> <p>If an invalid Component State is specified, an error will be generated and the data packet will be disregarded.</p>              |
| <p>Component Value 1 : Float IEEE : Component defined</p> <p>Valid Values:</p> <p>minimum to maximum allowed by the data format</p> <p>See the Component Control assignments in the applicable Database and Entity Attribute Definition Document (s).</p> <p>Default: N/A</p> | <p>This parameter specifies a continuous value to be applied to a Component.</p> <p>If an invalid Component Value is specified, an error will be generated and the data packet will be disregarded.</p> |
| <p>Component Value 2 : Float IEEE : Component defined</p> <p>Valid Values:</p> <p>minimum to maximum allowed by the data format</p> <p>See the Component Control assignments in the applicable Database and Entity Attribute Definition Document (s).</p> <p>Default: N/A</p> | <p>This parameter specifies a continuous value to be applied to a Component.</p> <p>If an invalid Component Value is specified, an error will be generated and the data packet will be disregarded.</p> |

### 5.3.4 Articulated Part Control


The Articulated Part data packet is contained in the Ethernet message sent from the Host to the IG. This data packet contains parameters to manipulate articulated parts such as flaps, slats, etc., that require articulation in six degrees of freedom.



The Articulated Part data packet can be used to control uniquely identified articulated parts of an entity. A unique articulated part is identified by its Part ID and is associated to a unique entity by the Entity ID. In this case the pitching of the left stabilator on an airframe.

**Figure 17 – Articulated Part Control Components**

Each articulated part (submodel) within a model contains its own local coordinate system. When a new position or orientation is specified for the part, the translation or rotation of the submodel is performed relative to this coordinate system. Figure 18 illustrates a flap's coordinate system.



**Figure 18 – Articulated Part Submodel Coordinate System**

The host can change any or all degrees of freedom of the articulated part as specified by the X Offset Enable, Y Offset Enable, Z Offset Enable, Roll Enable, Pitch Enable, and Yaw Enable parameters. If the host chooses not to activate a particular degree of freedom, that degree of freedom will be defaulted to the modeled default(s). If, however, the host enables a particular degree of freedom, the modeled default value will be overwritten and lost until the IG is restarted.

The contents of the Articulated Part Control data packet are shown below.

| 31                  | 30 | 29 | 28 | 27                | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16    | 15        | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|---------------------|----|----|----|-------------------|----|----|----|----|----|----|----|----|----|----|-------|-----------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| Packet ID = 4       |    |    |    | Packet = 32 bytes |    |    |    |    |    |    |    |    |    |    |       | Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Articulated Part ID |    |    |    |                   |    |    |    | *1 | *2 | *3 | *4 | *5 | *6 | *7 | Spare |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |                   |    |    |    |    |    |    |    |    |    |    |       | X Offset  |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |                   |    |    |    |    |    |    |    |    |    |    |       | Y Offset  |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |                   |    |    |    |    |    |    |    |    |    |    |       | Z Offset  |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |                   |    |    |    |    |    |    |    |    |    |    |       | Roll      |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |                   |    |    |    |    |    |    |    |    |    |    |       | Pitch     |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |                   |    |    |    |    |    |    |    |    |    |    |       | Yaw       |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

- \*1 Articulated Part State
- \*2 X Offset Enable
- \*3 Y Offset Enable
- \*4 Z Offset Enable
- \*5 Roll Enable
- \*6 Pitch Enable
- \*7 Yaw Enable

## Articulated Parts Parameter Definitions:

| Formats and Ranges  | Description  |
|---|--|
| Packet ID = 4 : unsigned char : N/A   | <p>This parameter identifies this data packet as an Articulated Part data packet.</p> <p>There can be multiple instances of this data packet per frame, but each unique articulated part should only be specified once per frame. If more than one data packet with the same Articulated Part ID is received in the same frame, the last one received will be used.</p>  |
| Packet Size : unsigned char : N/A   | This parameter indicates the number of bytes in this data packet.  |
| Articulated Part ID: signed char : N/A<br><br>Valid Values:<br><br>0 – 127 identifies a unique articulated part<br><br>See the articulated part identification assignments in the applicable Database and Entity Attribute Definition Document (s).<br><br>Default: N/A | <p>This parameter indicates which articulated part is controlled with this data packet.</p> <p>If the specified Articulated Part ID is not a valid part of the entity specified by the Entity ID, an error will be generated and the data packet will be disregarded.</p>  |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A   | <p>This parameter specifies the entity to which this data packet will be applied.</p> <p>If the specified entity id contains zero the parameters in this data packet will be applied to the Ownship. If the specified entity id contains a number greater than zero the parameters in this data packet will be applied to the specified entity.</p> <p>If the specified Entity ID is not active, an error will be generated and the data packet will be disregarded.</p> |
| Articulated Part State : Boolean : N/A<br><br>Valid Values:<br><br>0 = Inactive (removes the part from the scene)<br>1 = Active (introduces the part into the scene)<br><br>Default: 1  | This parameter indicates whether an articulated part is to be shown in the display (active) or not shown in the display (inactive).  |
| X Offset Enable : Boolean : N/A<br><br>Valid Values:<br><br>0 = Disable<br>1 = Enable<br><br>Default: N/A   | This parameter identifies whether the Articulated Part X Offset value contained in this data packet is manipulated from the Host (enabled). If the Host previously changed this degree of freedom and this switch is disabled the Articulated Part X Offset will remain where it was last placed.  |


|   |  |
|---|--|
| <p>Y Offset Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>   | <p>This parameter identifies whether the Articulated Part Y Offset value contained in this data packet is manipulated from the Host (enabled). If the Host previously changed this degree of freedom and this switch is disabled the Articulated Part Y Offset will remain where it was last placed.</p>   |
| <p>Z Offset Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>   | <p>This parameter identifies whether the Articulated Part Z Offset value contained in this data packet is manipulated from the Host (enabled). If the Host previously changed this degree of freedom and this switch is disabled the Articulated Part Z Offset will remain where it was last placed.</p>   |
| <p>Roll Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>   | <p>This parameter identifies whether the Articulated Part Roll value contained in this data packet is manipulated from the Host (enabled). If the Host previously changed this degree of freedom and this switch is disabled the Articulated Part Roll will remain where it was last placed.</p>   |
| <p>Pitch Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>  | <p>This parameter identifies whether the Articulated Part Pitch value contained in this data packet is manipulated from the Host (enabled). If the Host previously changed this degree of freedom and this switch is disabled the Articulated Part Pitch will remain where it was last placed.</p>   |
| <p>Yaw Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>  | <p>This parameter identifies whether the Articulated Part Heading value contained in this data packet is manipulated from the Host (enabled). If the Host previously changed this degree of freedom and this switch is disabled the Articulated Part Heading will remain where it was last placed.</p> <p>Note: This parameter was named “Enable/Disable Articulated Part Heading” in version 2.0 of this document. Its use has remained the same.</p> |
| <p>X Offset : Float IEEE : meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: Defined by model<br/>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the distance along the X-axis by which the articulated part should be moved. This parameter is ignored if the X Offset Enable field is set to Disable.</p>   |

|  |  |
|--|--|
| <p>Y Offset : Float IEEE : meters</p> <p>Valid Values:</p> <p>    Minimum to maximum allowed by the data format</p> <p>Default: Defined by model</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the distance along the Y-axis by which the articulated part should be moved. This parameter is ignored if the Y Offset Enable field is set to Disable.</p>   |
| <p>Z Offset : Float IEEE : meters</p> <p>Valid Values:</p> <p>    Minimum to maximum allowed by the data format</p> <p>Default: Defined by model</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the distance along the Z-axis by which the articulated part should be moved. This parameter is ignored if the Z Offset Enable field is set to Disable.</p>   |
| <p>Roll : Float IEEE : degrees</p> <p>Valid Values:</p> <p>    0 to +180 clockwise</p> <p>    0 to -180 counter clockwise</p> <p>Default: Defined by model</p> <p>Datum: see Figure 9.</p>                 | <p>This parameter specifies the roll of this part with respect to the submodel coordinate system. This parameter is ignored if the Roll Enable field is set to Disable.</p>  |
| <p>Pitch : Float IEEE : degrees</p> <p>Valid Values:</p> <p>    0 to +90 up</p> <p>    0 to -90 down</p> <p>Default: As set in the model's default</p> <p>Datum: see Figure 9.</p>                         | <p>This parameter specifies the pitch of this part with respect to the submodel coordinate system. This parameter is ignored if the Pitch Enable field is set to Disable.</p>  |
| <p>Yaw : Float IEEE : degrees</p> <p>Valid Values:</p> <p>    0 to +360 clockwise</p> <p>Default: Defined by model</p> <p>Datum: see Figure 9.</p>   | <p>This parameter specifies the yaw of this part with respect to the submodel coordinate system. This parameter is ignored if the Yaw Enable field is set to Disable.</p> <p>Note: This parameter was named "Articulated Part Heading" in version 2.0 of this document. Its use has remained the same.</p> |

### 5.3.5 Rate Control

The Rate Control data packet is contained in the Ethernet message sent from the Host to the IG. This data packet contains rate information that supplement the Entity Control data packet or the Articulated Part Control data packet as needed. An entity is normally placed using the attitude and positional data received in the Entity Control data packet. If reception of an Entity Control data packet is discontinued and a Rate Control data packet was received, the rate information in the Rate Control data packet will be used to continue the entity's movement by extrapolation of the entity's position along the given velocity vector with the specified angular rates. The IG will use the placement and rate information from a prior frame as the basis for the extrapolation. In the event that a new Entity Control data packet is received at some later time, the entity position will be updated and extrapolation will continue from that location. Setting all rate components to zero will cause the entity to be stationary.

This data packet may also be used to animate articulated parts modeled within an entity, or child parts attached to a parent model. Given proper angular rates, the IG will extrapolate these components to simulate such things as spinning propellers, rotating wheels, etc.



**Figure 19 – Rate Control Components**

The contents of the Rate Control data packet are shown below.

|                     |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|---------------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|-----------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31                  | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15        | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 5       |    |    |    |    |    |    |    | Packet Size = 32 bytes |    |    |    |    |    |    |    | Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Articulated Part ID |    |    |    |    |    |    |    | Spare                  |    |    |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |    |    |    |    | X Linear Rate          |    |    |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |    |    |    |    | Y Linear Rate          |    |    |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |    |    |    |    | Z Linear Rate          |    |    |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |    |    |    |    | Roll Angular Rate      |    |    |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |    |    |    |    | Pitch Angular Rate     |    |    |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                     |    |    |    |    |    |    |    | Yaw Angular Rate       |    |    |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

Rate Control Parameter Definitions:

| Formats and Ranges   | Description   |
|--|---|
| Packet ID = 5 : unsigned char : N/A  | This parameter identifies this data packet as the Rate Control data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique Rate Control data packet should only be specified once per frame. If more than one data packet with the same Entity ID, or the same Entity ID and associated Articulated Part ID is received in the same frame, the last one received will be used.   |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.   |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A  | This parameter specifies the entity to which this data packet will be applied.<br><br>If the specified entity ID contains zero, the parameters in this data packet will be applied to the Ownship. If the specified entity ID contains a number greater than zero, the parameters in this data packet will be applied to the specified entity.<br><br>If the specified Entity ID is not active, an error will be generated and the data packet will be disregarded. |
| Articulated Part ID: signed char : N/A<br><br>Valid Values:<br><br>-1 = Apply rates to entity only<br>0 – 127 identifies a unique articulated part<br><br>See the articulated part identification assignments in the applicable Database and Entity Attribute Definition Document (s).<br><br>Default: N/A | This parameter indicates which articulated part is controlled with this data packet. If the data is meant to control the entity only, a -1 should be placed in this field.<br><br>If the specified Articulated Part ID is not a valid part of the entity specified by the Entity ID, an error will be generated and the data packet will be disregarded.  |



|   |   |
|---|---|
| <p>X Linear Rate : Float IEEE : meters per second</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format<br/>       (+) forward direction<br/>       (-) backward direction</p> <p>Default: 0<br/>       Datum: see See description at right</p>     | <p>This parameter specifies the X component of the velocity vector for the entity being represented.</p> <p>If this packet refers to an entity, this component value is relative to the world (Geodetic) coordinate system.</p> <p>If this packet refers to an articulated part, this component value is relative to the entity's body coordinate system.</p> <p>Note: This parameter was named “<math>V_x</math> Component of the Velocity Vector” in version 2.0 of this document. Its use has remained the same.</p> |
| <p>Y Linear Rate : Float IEEE : meters per second</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format<br/>       (+) right wing direction<br/>       (-) left wing direction</p> <p>Default: 0<br/>       Datum: see See description at right</p> | <p>This parameter specifies the Y component of the velocity vector for the entity being represented.</p> <p>If this packet refers to an entity, this component value is relative to the world (Geodetic) coordinate system.</p> <p>If this packet refers to an articulated part, this component value is relative to the entity's body coordinate system.</p> <p>Note: This parameter was named “<math>V_y</math> Component of the Velocity Vector” in version 2.0 of this document. Its use has remained the same.</p> |
| <p>Z Linear Rate : Float IEEE : meters per second</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format<br/>       (+) downward direction<br/>       (-) upward direction</p> <p>Default: 0<br/>       Datum: See description at right</p>          | <p>This parameter specifies the Z component of the velocity vector for the entity being represented.</p> <p>If this packet refers to an entity, this component value is relative to the world (Geodetic) coordinate system.</p> <p>If this packet refers to an articulated part, this component value is relative to the entity's body coordinate system.</p> <p>Note: This parameter was named “<math>V_z</math> Component of the Velocity Vector” in version 2.0 of this document. Its use has remained the same.</p> |
| <p>Roll Angular Rate : Float IEEE : degrees per second</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format<br/>       (+) right wing down<br/>       (-) left wing down</p> <p>Default: 0<br/>       Datum: See description at right</p>          | <p>This parameter specifies the roll angular rate for the entity being represented.</p> <p>If this packet refers to an entity, this component value is relative to the world (Geodetic) coordinate system.</p> <p>If this packet refers to an articulated part, this component value is relative to the entity's body coordinate system.</p>  |

|   |  |
|---|--|
| <p>Pitch Angular Rate : Float IEEE : degrees per second</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format<br/>       (+) nose up direction<br/>       (-) nose direction</p> <p>Default: 0<br/>       Datum: See description at right</p>             | <p>This parameter specifies the pitch angular rate for the entity being represented.</p> <p>If this packet refers to an entity, this component value is relative to the world (Geodetic) coordinate system.</p> <p>If this packet refers to an articulated part, this component value is relative to the entity's body coordinate system.</p>  |
| <p>Yaw Angular Rate : Float IEEE : degrees per second</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format<br/>       (+) clockwise direction<br/>       (-) counterclockwise direction</p> <p>Default: 0<br/>       Datum: See description at right</p> | <p>This parameter specifies the yaw angular rate for the entity being represented.</p> <p>If this packet refers to an entity, this component value is relative to the world (Geodetic) coordinate system.</p> <p>If this packet refers to an articulated part, this component value is relative to the entity's body coordinate system.</p> <p>Note: This parameter was named "Heading Angular Rate" in version 2.0 of this document. Its use has remained the same.</p> |

**5.3.6 Environment Control**

The Environment Control data packet is contained in the Ethernet message sent from the Host to the IG. The Environment Control data packet allows the Host to control the global environment parameters for a given mission scenario. The image generator provides a simulation of the position of the sun and moon based on its internal ephemeris model. The time of day is continuously incremented based on this ephemeris model unless the model is turned off, in which case the time of day will remain at the exact values provided in the Hour and Minute parameters of this data packet. If the Host submits time-of-day information while the ephemeris model is enabled, the current time of day will be changed to the values supplied by the Host, and the ephemeris model will continue to update the value thereafter. Care should be taken when sending this data packet because when the IG receives it, all data parameters contained in the data packet will be updated. If the Environment values are outside the range specified, an error will be returned to the Host and the data packet will be disregarded.

The CIGI Environmental Control data packet contains parameters to support the Moderate Resolution Transmittance (MODTRAN) Code. MODTRAN is a fully validated, government standard software package for calculating important atmospheric quantities such as transmittance and radiance. MODTRAN calculates the atmospheric path transmittance and path radiance values for frequencies from 0 to 50,000 cm<sup>-1</sup>, with a spectral resolution of approximately 2 cm<sup>-1</sup> (20 cm<sup>-1</sup> in the UV portion of the spectrum).

Sun and moon positions, moon phase, and horizon glow are computed by the image generator and do not require Host control.

The contents of the Environment data packet are shown below.

|                     |          |    |    |    |    |    |    |                        |       |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
|---------------------|----------|----|----|----|----|----|----|------------------------|-------|----|----|----|----|----|----|------|----|----|----|--------|----|---|---|---|---|---|---|---|---|---|---|--|--|--|--|
| 31                  | 30       | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22    | 21 | 20 | 19 | 18 | 17 | 16 | 15   | 14 | 13 | 12 | 11     | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |  |  |  |  |
| Packet ID = 6       |          |    |    |    |    |    |    | Packet Size = 36 bytes |       |    |    |    |    |    |    | Hour |    |    |    | Minute |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
| *1                  | Humidity |    |    |    |    |    |    | *2                     | Spare |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
| Date                |          |    |    |    |    |    |    |                        |       |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
| Air Temperature     |          |    |    |    |    |    |    |                        |       |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
| Global Visibility   |          |    |    |    |    |    |    |                        |       |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
| Wind Speed          |          |    |    |    |    |    |    |                        |       |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
| Wind Direction      |          |    |    |    |    |    |    |                        |       |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
| Barometric Pressure |          |    |    |    |    |    |    |                        |       |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |
| Aerosol             |          |    |    |    |    |    |    |                        |       |    |    |    |    |    |    |      |    |    |    |        |    |   |   |   |   |   |   |   |   |   |   |  |  |  |  |

- \*1 Ephemeris Enable
- \*2 MODTRAN Enable

Environment Control Parameter Definitions:

| Formats and Ranges   | Description  |
|--|--|
| Packet ID = 6 : unsigned char : N/A  | This parameter identifies this data packet as the Environment Control data packet.<br><br>There can be only one instance of this data packet per frame. If more than one data packet is received the last one received will be used. |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.  |
| Hour : unsigned char : hours<br><br>Valid Values:<br>0 – 23<br><br>Default: 0<br>Datum: Local time | This parameter specifies the hour of the day for the ephemeris program within the image generator.   |

|  |   |
|--|---|
| Minute : unsigned char : minutes<br>Valid Values:<br>0 – 59<br>Default: 0<br>Datum: Local time   | This parameter specifies the minute of the hour for the ephemeris program within the image generator.   |
| Ephemeris Enable : Boolean : N/A<br>Valid Values:<br>0 = Disabled (Static Time of Day)<br>1 = Enabled (Continuous Time of Day)<br>Default: 0                                 | This parameter controls whether a continuous time of day or static time of day is used for a mission. If set to continuous, the image generator will update the time of day.  |
| Humidity : unsigned 7 bit field : percent<br>Valid Values:<br>0 to 100<br>101 to 127 are invalid<br>Default: 0   | This parameter specifies the global humidity of the environment.  |
| MODTRAN Enable : Boolean : N/A<br>Valid Values:<br>0 = Off<br>1 = On<br>Default: 0   | This parameter determines whether atmospheric will be included in the calculations. An “Off” setting means that source radiance will be calculated, whereas, an “On” setting means that apparent radiance will be calculated. |
| Date : integer : MMDDYYYY<br>Valid Values:<br>$\text{MMDDYYYY} = (\text{month number} \times 1000000) + (\text{day number} \times 10000) + \text{year number}$<br>Default: 0 | This parameter specifies the desired date for use by the ephemeris program within the image generator.  |
| Air Temperature : Float IEEE: degrees Celsius<br>Valid Values:<br>Minimum to maximum allowed by the data format<br>Default: 0.0  | This parameter specifies the global temperature of the environment.   |
| Global Visibility : Float IEEE: meters<br>Valid Values:<br>0 to maximum allowed by the data format<br>Default: 0.0   | This parameter specifies the global visibility.   |

|  |   |
|--|---|
| Wind Speed : Float IEEE: meters per second                                 | This parameter specifies the global wind speed.   |
| Valid Values:<br>0 to maximum allowed by the data format<br>Default: 0.0   |   |
| Wind Direction : Float IEEE: degrees                                       | This parameter specifies the global wind direction.   |
| Valid Values:<br>0 to +360 clockwise<br>Default: 0.0<br>Datum: True North  |   |
| Barometric Pressure : Float IEEE: millibars (mb)                           | This parameter controls the atmospheric pressure input into MODTRAN. Typically, this will default to the value used when defining the model atmosphere.         |
| Valid Values:<br>0.0 to maximum allowed by the data format<br>Default: 0.0 |   |
| Aerosol : Float IEEE: gm/m <sup>3</sup>                                    | This parameter controls the liquid water content for the defined atmosphere. Typically, this will default to the value used when defining the model atmosphere. |
| Valid Values:<br>0.0 to maximum allowed by the data format<br>Default: 0.0 |   |

**5.3.7 Weather Control**

The Weather Control data packet is contained in the Ethernet message sent from the Host to the IG. This data packet is used to control and/or override default local or layered weather phenomena. The parameters within this data packet allow for the descriptions of haze, ground fog, rain, cloud layers, etc. When the data packet is used to represent ground fog, the Host is responsible for maintaining the relationship between visibility and Runway Visual Range via the Runway Visibility Range parameter of this data packet.



**Figure 20 – Cloud Elevation and Thickness**

Particular weather phenomena may be assigned to an entity. Hence, position/orientation controls for weather are controlled via the Entity Control data packet for these types. Also, when a Weather Control data packet is used to control a weather phenomenon entity, the Temperature and Opacity parameters within the packet are ignored. These properties should instead be set via the Entity Control packet.

Some attributes may not apply to a particular weather layer or phenomenon. In such cases, only the applicable parameters need to contain valid data; the remaining parameters will be ignored by the IG. For example, a thunderstorm phenomenon entity might need only to use the Packet ID, Packet Size, Entity ID, Weather State, Severity, and Phenomenon Type parameters. All other parameters would be ignored since the phenomenon’s temperature and opacity would be set via the Entity Control packet and the remaining parameters would not apply.

The contents of the Weather Control data packet are shown below.

|                                 |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|---------------------------------|----|----|----|----|----|----|-------|------------------------|----|----|----|----|----|----|-----------------|-----------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31                              | 30 | 29 | 28 | 27 | 26 | 25 | 24    | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16              | 15        | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 7                   |    |    |    |    |    |    |       | Packet Size = 44 bytes |    |    |    |    |    |    |                 | Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| *1                              | *2 | *3 | *4 |    |    |    | Spare |                        |    |    |    |    |    |    | Phenomenon Type |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Air Temperature                 |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Opacity/Runway Visibility Range |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Scud Frequency                  |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Coverage                        |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Elevation                       |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Thickness                       |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Transition Band                 |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Winds Aloft Speed               |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Winds Aloft Direction           |    |    |    |    |    |    |       |                        |    |    |    |    |    |    |                 |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

- \*1 Weather Enable
- \*2 Scud Enable
- \*3 Random Winds Aloft
- \*4 Severity

## Weather Control Parameter Definitions:

| Formats and Ranges  | Description   |
|---|---|
| Packet ID = 7 : unsigned char : N/A   | This parameter identifies this data packet as the Weather Control data packet.<br><br>There can be multiple instances of this data packet per frame. Each instance should uniquely identify a weather phenomenon via the Entity ID parameter in this data packet.                                   |
| Packet Size : unsigned char : N/A   | This parameter indicates the number of bytes in this data packet.   |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A               | This parameter indicates the Entity ID, i.e. Entity Control data packet to which this weather model is assigned. This field may be valid only for particular local weather phenomena (e.g. thunderstorms, fronts, and sandstorms). This parameter is only used when Phenomenon Type is set to zero. |
| Weather Enable : Boolean : N/A<br><br>Valid Values:<br><br>0 = Disable<br>1 = Enable<br><br>Default: 0    | This parameter indicates whether the phenomena specified by this data packet is visible (Enable) or not (Disable).  |
| Scud Enable : Boolean : N/A<br><br>Valid Values:<br><br>0 = Disable<br>1 = Enable<br><br>Default: 0       | This parameter indicates whether there will be scud effects applied to the phenomenon specified by this data packet.<br><br>If this parameter is applied to the ground fog layer, it will cause a patchy fog effect.  |
| Random Winds Aloft: Boolean : N/A<br><br>Valid Values:<br><br>0 = Disable<br>1 = Enable<br><br>Default: 0 | This parameter indicates whether a random frequency and duration should be applied to the Winds Aloft value. This is meant to provide for gusting winds. Winds Aloft will enable phenomenon drift contrasting with the global winds parameters defined in the Environment Control data packet.      |
| Severity : 3 bit field : N/A<br><br>Valid Values:<br><br>0 – 5 Least to most severe<br><br>Default: 0     | This parameter indicates the severity of the weather phenomenon. This parameter can be used to control such things as thunderstorm severity or sea state.   |

|  |  |
|--|--|
| <p>Phenomenon Type : unsigned short: N/A</p> <p>Valid Values:</p> <p>0 = Use Entity ID<br/> 1 = Cloud Layer 1<br/> 2 = Cloud Layer 2<br/> 3 = Ground Fog<br/> 4 = Rain<br/> 5 = Snow<br/> 6 = Sand<br/> 7 to 65535 defined by the IG</p> <p>Default: N/A</p> | <p>This parameter indicates the type of weather described by this data packet. Values zero through six are provided to establish a common numbering scheme for standard layered weather.</p>   |
| <p>Air Temperature : Float IEEE: degrees Celsius</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: 0.0<br/> Datum: 0° C</p>  | <p>This parameter indicates the local temperature inside the weather phenomenon.</p> <p>This value is ignored if Phenomenon Type is set to zero. To specify air temperature for a weather entity, set the Temperature parameter in the Entity Control packet.</p>  |
| <p>Opacity : Float IEEE: Percent</p> <p>Valid Values:</p> <p>0 to 100%</p> <p>Default: 0</p> <p>----- Or -----</p>   | <p>This parameter indicates the opacity of the weather phenomenon. One hundred percent opacity produces zero visibility through the phenomena. This control is meant to provide a transmissive or density effect for the weather (e.g. wispy clouds, rain severity, snow severity).</p> <p>This value is ignored if Phenomenon Type is set to zero. To specify opacity for a weather entity, set the Opacity parameter in the Entity Control packet.</p> |
| <p>Runway Visibility Range : Float IEEE: meters</p> <p>Valid Values:</p> <p>0 to &lt; global visibility</p> <p>Default: 0</p>  | <p>This parameter indicates the distance from the eye point to a point where the scene is completely fogged. This parameter is valid only when the Phenomenon Type is set to Ground Fog (3).</p>   |
| <p>Scud Frequency : Float IEEE: Percent</p> <p>Valid Values:</p> <p>0 to 100%</p> <p>Default: 0</p>  | <p>This parameter indicates the frequency of the scud effect. Valid values range from 0% meaning no scud affect, to 100%, which indicates a solid effect.</p> <p>If this parameter is applied to the ground fog layer, it will cause a patchy fog effect.</p>  |
| <p>Coverage : Float IEEE: Percent</p> <p>Valid Values:</p> <p>0 to 100%</p> <p>Default: 0</p>  | <p>This parameter indicates the amount of area coverage a particular phenomenon has over the specified global visibility range given in the Environment Control data packet (e.g., 100% for a cloud layer produces a solid cloud layer).</p>   |



|  |  |
|--|--|
| <p>Elevation : Float IEEE: meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: 0</p> <p>Datum: Mean Sea Level</p>   | <p>This parameter indicates the base (bottom) altitude of the weather phenomenon.</p>  |
| <p>Thickness : Float IEEE: meters</p> <p>Valid Values:</p> <p>0 to maximum allowed by the data format</p> <p>Default: 0</p> <p>Datum: Elevation upward as defined in this data packet.</p>   | <p>This parameter indicates the vertical thickness of the weather phenomenon. When applied to clouds or fog, the altitude at the top of the layer is equal to the elevation plus the thickness.</p>  |
| <p>Transition Band : Float IEEE: meters</p> <p>Valid Values:</p> <p>0 to maximum allowed by the data format</p> <p>Default: 0</p> <p>Datum: As defined in this data packet, Elevation downward for the bottom and Elevation plus Thickness upward for the top.</p> | <p>This parameter indicates a vertical transition band both above and below (if applicable) a phenomenon. Within this band, visibility transitions from the specified opacity to the global visibility value given in the Environment Control data packet.</p> |
| <p>Winds Aloft Speed</p> <p>0 to maximum allowed by the data format</p> <p>Default: 0</p>  | <p>This parameter indicates the local wind speed applied to the phenomenon. Setting this parameter to zero disables Winds Aloft.</p>   |
| <p>Winds Aloft Direction : Float IEEE: degrees</p> <p>Valid Values:</p> <p>0 to +360 clockwise</p> <p>Default: 0</p> <p>Datum: True North</p>  | <p>This parameter indicates local direction of the wind applied to the phenomenon.</p>   |

### 5.3.8 View Control

The View Control data packet is contained in the Ethernet message sent from the Host to the IG. It is used to attach a view to an entity and to define the position and orientation of the view relative to the entity's reference point. This concept can be used to specify view offsets that may be used for such things as pilot eye, weapon/sensor viewpoints, and stealth views. It should be noted that the number of views might be limited by the IG configuration. It is also assumed that the characteristics of a view found in the View Definition data packet of this interface are defaulted within the IG or must be specified by the View Definition data packet in section 5.3.12.

A view or view group may be positioned and/or rotated with respect to the entity's body axes as described in Section 4.3. The order of operation for manipulating the view must be such that the view is translated along the X, Y, and Z axes and then rotated about the Z, Y, and then X axes (i.e. applying yaw, pitch and then roll). This data packet should be supplied to the IG at mission initialization and then again any time the view must be moved relative to an entity's reference point.




Figure 21 – View Point Offset and Orientation from Entity Reference

The contents of the View Control data packet are shown below.

|               |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |           |    |    |    |       |    |   |   |   |   |   |   |   |   |   |   |
|---------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|-----------|----|----|----|-------|----|---|---|---|---|---|---|---|---|---|---|
| 31            | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15        | 14 | 13 | 12 | 11    | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 8 |    |    |    |    |    |    |    | Packet Size = 32 bytes |    |    |    |    |    |    |    | Entity ID |    |    |    |       |    |   |   |   |   |   |   |   |   |   |   |
| View ID       |    |    |    | *1 |    |    |    | *2                     |    | *3 |    | *4 |    | *5 |    | *6        |    | *7 |    | Spare |    |   |   |   |   |   |   |   |   |   |   |
|               |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | X Offset  |    |    |    |       |    |   |   |   |   |   |   |   |   |   |   |
|               |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Y Offset  |    |    |    |       |    |   |   |   |   |   |   |   |   |   |   |
|               |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Z Offset  |    |    |    |       |    |   |   |   |   |   |   |   |   |   |   |
|               |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Roll      |    |    |    |       |    |   |   |   |   |   |   |   |   |   |   |
|               |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Pitch     |    |    |    |       |    |   |   |   |   |   |   |   |   |   |   |
|               |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Yaw       |    |    |    |       |    |   |   |   |   |   |   |   |   |   |   |

- \*1 View Group Select
- \*2 X Offset Enable
- \*3 Y Offset Enable
- \*4 Z Offset Enable
- \*5 Roll Enable
- \*6 Pitch Enable
- \*7 Yaw Enable

View Control Parameter Definitions:

| Formats and Ranges                                      | Description   |
|---|---|
| Packet ID = 8 : unsigned char : N/A                     | <p>This parameter identifies this data packet as a View Control data packet.</p> <p>There can be multiple instances of this data packet per frame, but each unique view control should only be specified once per frame. If more than one data packet with the same Entity ID and View ID or View Group Select is received in the same frame, the last one received will be used.</p> |
| Packet Size : unsigned char : N/A                       | This parameter indicates the number of bytes in this data packet.   |
| Entity ID : unsigned short : N/A                        | This parameter indicates the entity to which this view should be attached.  |
| Valid Values:<br><br>0 to 65535<br><br>Default: N/A     |   |
| View ID: 5 bit field: N/A                               | This parameter specifies which view position is associated with offsets and rotations specified by this data packet.  |
| Valid Values:<br><br>0 – 31 View ID<br><br>Default: N/A | If the Host requests a view that has not been configured on the IG, an error will be generated and the data packet will be disregarded  |

|   |   |
|---|---|
| <p>View Group Select: 3 bit field: N/A</p> <p>Valid Values:</p> <p>0 Apply to single view<br/>1 – 7 Apply to view group</p> <p>Default: N/A</p> | <p>This parameter specifies which view group is to be controlled by the offsets specified by this data packet. View groups are defined using the View Definition data packet. When this parameter is 0, the field is disregarded, and position control is performed on an individual view specified by the View ID in this data packet. Otherwise, the transformation is applied to each view in the specified group.</p> <p>If the Host requests a group that has not been defined by the View Definition data packet and has not been pre-configured on the IG, an error will be generated and the data packet will be disregarded.</p> |
| <p>X Offset Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>                               | <p>This parameter identifies whether the X Offset parameter should be applied to the specified view or view group. If this flag is set to 0 (Disable), the X Offset parameter is ignored.</p>   |
| <p>Y Offset Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>                               | <p>This parameter identifies whether the Y Offset parameter should be applied to the specified view or view group. If this flag is set to 0 (Disable), the Y Offset parameter is ignored.</p>   |
| <p>Z Offset Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>                               | <p>This parameter identifies whether the Z Offset parameter should be applied to the specified view or view group. If this flag is set to 0 (Disable), the Z Offset parameter is ignored.</p>   |
| <p>Roll Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>                                   | <p>This parameter identifies whether the Roll parameter should be applied to the specified view or view group. If this flag is set to 0 (Disable), the Roll parameter is ignored.</p>   |
| <p>Pitch Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>                                  | <p>This parameter identifies whether the Pitch parameter should be applied to the specified view or view group. If this flag is set to 0 (Disable), the Pitch parameter is ignored.</p>   |

|   |   |
|---|---|
| <p>Yaw Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>    0 = Disable<br/>    1 = Enable</p> <p>Default: N/A</p>  | <p>This parameter identifies whether the Yaw parameter should be applied to the specified view or view group. If this flag is set to 0 (Disable), the Yaw parameter is ignored.</p> <p>Note: This parameter was named “Enable/Disable View Heading” in version 2.0 of this document. Its use has remained the same.</p> |
| <p>X Offset: Float IEEE : meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: Specified by IG Configuration<br/>Datum: Entity coordinate system, see Figure 9.</p>           | <p>This parameter is used to define the X component of the view offset vector along the entity’s longitudinal axis, as shown in Figure 21.</p>  |
| <p>Y Offset: Float IEEE : meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: Specified by IG Configuration<br/>Datum: Entity coordinate system, see Figure 9.</p>           | <p>This parameter is used to define the Y component of the view offset vector along the entity’s lateral axis, as shown in Figure 21.</p>   |
| <p>Z Offset: Float IEEE : meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: Specified by IG Configuration<br/>Datum: Entity coordinate system, see Figure 9.</p>           | <p>This parameter is used to define the Z component of the view offset vector along the entity’s vertical axis, as shown in Figure 21.</p>  |
| <p>Roll: Float IEEE: degrees</p> <p>Valid Values:</p> <p>    0 to +180 clockwise<br/>    0 to –180 counter clockwise</p> <p>Default: Specified by IG Configuration<br/>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the rotation about the view’s X axis, as shown in Figure 21.</p>  |
| <p>Pitch: Float IEEE: degrees</p> <p>Valid Values:</p> <p>    0 to +90 up<br/>    0 to –90 down</p> <p>Default: Specified by IG Configuration<br/>Datum: Entity coordinate system, see Figure 9.</p>                      | <p>This parameter specifies the rotation about the view’s Y axis, as shown in Figure 21.</p>  |

Yaw : Float IEEE: degrees

Valid Values:

0 to +360 clockwise

Default: Specified by IG Configuration

Datum: Entity coordinate system, see Figure 9.


This parameter specifies the rotation about the view's Z axis, as shown in Figure 21.

Note: This parameter was named "View Heading" in version 2.0 of this document. Its use has remained the same.

**5.3.9 Sensor Control**

The Sensor Control data packet is contained in the Ethernet message sent from the Host to the IG. This data packet, in conjunction with the View Control, View Definition, Component Control, and LOS Range Request data packets, control and describe the abilities of a sensor-based weapon system.

This Sensor Control data packet will provide sensor mode-of-operation and display behavior. This data packet is associated with a particular view via the View ID parameter. This allows for positioning and orienting a sensor with respect to an entity. Field-of-view characteristics may be controlled using a View Definition data packet, which is also associated with a view using the View ID parameter of that data packet. Discrete sensor attributes are controlled using one or more Component Control data packets. These data packets are also associated with a particular view via the View ID parameter of the data packets. The Line-of-Sight Range Request data packet is used to request a Line-of-Sight Range Response data packet from the IG that contains the intersection point on the database along the Line-of-Sight vector based on the sensor position and orientation specified in the View Control data packet.



**Figure 22 – Sensor Definition Components**

When a Sensor Control data packet is sent from the Host, associated Component Control and LOS Range Request data packets may also be sent. It will be useful to the Host to know which series of data packets are associated with the same request. Even though the LOS Range Request has a unique LOS ID it may be useful to have the Host internally associate these packets together via the Sensor ID parameter of the Sensor Control data packet. To match up Sensor Control and other associated data packets from the host with responses from the IG, the Sensor ID parameter is used. The same number that is placed in this parameter will be returned in the Sensor ID parameter of the corresponding Sensor Response data packet as described in section 5.4.5. The Sensor ID value should be manipulated in such a way as to not duplicate the value in a reasonable amount of time (typically one second). This will prevent similarly identified requests from being lost by the IG.

There is no restriction on the number of Sensor Control data packets that can be sent in a single frame. The user should be aware, however, that the response time of the IG might be degraded under conditions that overload the IG Sensor computation mechanism.

The contents of the Sensor Control data packet are shown below.

|               |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |         |    |    |    |    |    |           |   |   |   |   |   |   |   |   |   |
|---------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|---------|----|----|----|----|----|-----------|---|---|---|---|---|---|---|---|---|
| 31            | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15      | 14 | 13 | 12 | 11 | 10 | 9         | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 9 |    |    |    |    |    |    |    | Packet Size = 24 bytes |    |    |    |    |    |    |    | View ID |    |    | *1 | *2 | *3 | Sensor ID |   |   |   |   |   |   |   |   |   |
| *4            |    |    |    | *5 |    | *6 |    | Spare                  |    |    |    |    |    |    |    |         |    |    |    |    |    |           |   |   |   |   |   |   |   |   |   |
| Gain          |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Level   |    |    |    |    |    |           |   |   |   |   |   |   |   |   |   |
| AC Coupling   |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Noise   |    |    |    |    |    |           |   |   |   |   |   |   |   |   |   |

- \*1 Sensor On/Off
- \*2 Polarity
- \*3 Line-by-Line Dropout
- \*4 Track Mode
- \*5 Automatic Gain
- \*6 Track White/Black

Sensor Control Parameter Definitions:

| Formats and Ranges  | Description   |
|---|---|
| Packet ID = 9 : unsigned char : N/A   | This parameter identifies this data packet as a Sensor Control data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique sensor control should only be specified once per frame. If more than one data packet with the same View ID and Sensor ID is received in the same frame, the last one received will be used. |
| Packet Size : unsigned char : N/A   | This parameter indicates the number of bytes in this data packet.   |
| View ID: 5 bit field: N/A<br><br>Valid Values:<br><br>0 Not Used<br>1 – 31 Weapon Sensor view point | This parameter dictates to which view the corresponding sensor is assigned, regardless of the view group. The offsets associated with a view are specified via the View Control data packet.  |
| Default: N/A  |   |



|   |   |
|---|---|
| <p>Sensor On/Off : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Off<br/>1 = On</p> <p>Default: 0</p>   | <p>This parameter indicates whether this Sensor is turned on or off.</p>  |
| <p>Polarity : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = White Hot<br/>1 = Black Hot</p> <p>Default: 0</p>   | <p>This parameter indicates whether this Sensor is showing white hot or black hot.</p>  |
| <p>Line-by-Line Dropout : Boolean : N/A</p> <p>valid value:</p> <p>0 = Off<br/>1 = On</p> <p>Default: 0</p>   | <p>This parameter indicates whether the line-by-line drop-out feature is enabled.</p>   |
| <p>Sensor ID : unsigned char : N/A</p> <p>Valid Values:</p> <p>0 to 255</p> <p>Default: 0</p>   | <p>This parameter identifies the sensor to which this packet should be applied.</p>   |
| <p>Track Mode : 4 bit field: N/A</p> <p>Valid Values:</p> <p>0 = Off<br/>1 = Force Correlate<br/>2 = Scene<br/>3 = Target<br/>4 = Ship<br/>5 – 15 invalid</p> <p>Default: 0</p> | <p>This parameter indicates which track mode the sensor should use:</p> <p><i>Force Correlate</i> – The maverick seeker image-processes a portion of the view, establishes an image pattern, and attempts to keep the seeker pointed at the center of this image pattern.</p> <p><i>Scene</i> – The FLIR seeker image-processes a portion of the view, establishes an image pattern, and attempts to keep the seeker pointed at the center of this image pattern.</p> <p><i>Target</i> – Contrast tracking is locked to a specific (target) area.</p> <p><i>Ship</i> – Contrast tracking, where the tracking point is adjusted so that the weapon strikes close to the water line.</p> <p>If an invalid value is received, an error will be generated and not further action will be taken.</p> |

|                                   |   |
|-----------------------------------|---|
| Automatic Gain: Boolean: N/A      | This parameter, when set to “on,” causes the Weapons Sensor to automatically adjust the gain value to optimize the brightness and contrast of the sensor display. |
| Valid Values:                     |   |
| 0 = Off                           |   |
| 1 = On                            |   |
| Default: 0                        |   |
| Track White /Black : Boolean: N/A | This parameter causes the Weapons Sensor to track either white or black.  |
| Valid Values:                     |   |
| 0 = White                         |   |
| 1 = Black                         |   |
| Default: 0                        |   |
| Gain : Float IEEE : N/A           | This parameter indicates the gain value for the weapon sensor option.   |
| Valid values:                     | Gain and Level are used together to improve the contrast of the target imagery.   |
| 0.0 to 1.0                        |   |
| Default: 0.0                      |   |
| Level : Float IEEE : N/A          | This parameter indicates the level value for the weapon sensor option.  |
| Valid values:                     | Level and Gain are used together to improve the contrast of the target imagery.   |
| 0.0 to 1.0                        |   |
| Default: 0.0                      |   |
| AC Coupling : Float IEEE : N/A    | This parameter indicates the AC Coupling decay rate for the weapon sensor option.   |
| Valid values:                     | This feature is only available when the IG is equipped with enhanced Weapons Sensor effects.  |
| 0.0 to 1.0                        |   |
| Default: 0.0                      |   |
| Noise : Float IEEE : N/A          | This parameter indicates the detector-noise gain for the weapon sensor option.  |
| Valid values:                     |   |
| 0.0 to 1.0                        |   |
| Default: 0.0                      |   |

### 5.3.10 Trajectory Definition

The Trajectory Definition data packet is contained in the Ethernet message sent from the Host to the IG. This data packet is used in conjunction with the Entity Control, the Special Effects Definition, and the Rate data packets to define aspects of an object's trajectory. The Entity Control data packet will provide the initial position for the trajectory. If the entity is attached to another entity, then the positional data will be used as an offset from the parent's reference point. Other applicable Entity Control parameters may also apply. The Special Effects Definition data packet will provide effects duration, burst count, separation, color, etc.; the Rate data packet will provide the initial velocity components.




Figure 23 – Trajectory Definition Components

The contents of the Trajectory Definition data packet are shown below.

|                     |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |                  |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|---------------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|------------------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31                  | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15               | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 21      |    |    |    |    |    |    |    | Packet Size = 16 bytes |    |    |    |    |    |    |    | Entity ID        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Acceleration factor |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Retardation rate |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Terminal velocity   |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |                  |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

Trajectory Definition Parameter Definitions:

| Formats and Ranges   | Description  |
|--|--|
| Packet ID = 21 : unsigned char : N/A   | This parameter identifies this data packet as the Trajectory Definition data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique trajectory definition should only be specified once per frame. If more than one data packet with the same Entity ID is received in the same frame, the last one received will be used.    |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.  |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A  | This parameter indicates which entity is being influenced by this trajectory behavior. The specified Entity ID must have been previously defined. If this data packet is sent without a previously defined Entity ID either earlier in the same Ethernet message or in an earlier Ethernet message, an error will be generated and this data packet will be ignored. |
| Acceleration factor : Float IEEE: meters/second <sup>2</sup><br><br>Valid Values:<br><br>0 to maximum allowed by the data format<br><br>Default: N/A | This parameter indicates the acceleration factor that will be applied to the Vz component of the velocity vector over time to simulate the effects of gravity on the object.   |
| Retardation rate : Float IEEE: meters/second<br><br>Valid Values:<br><br>0 to maximum allowed by the data format<br><br>Default: N/A                 | This parameter indicates what retardation factor will be applied to the object’s motion. This factor will be used to proportionally reduce the Vx, Vy and Vz components of the velocity vector over time until they reach zero to simulate the effect of frictional forces acting upon the object.   |
| Terminal Velocity : Float IEEE: meters/second<br><br>Valid Values:<br><br>0 to maximum allowed by the data format<br><br>Default: N/A                | This parameter indicates what final velocity the object will be allowed to obtain.   |

**5.3.11 Special Effect Definition**

The Special Effect Definition data packet is contained in the Ethernet message sent from the Host to the IG. This data packet is used in conjunction with the Entity Control data packet to override the default-modeled parameters within an effect. The effect must be instanced via an Entity Control data packet either earlier in the same Ethernet message or in an earlier Ethernet message before the Special Effects Definition can be applied.

The contents of the Special Effect Definition data packet are shown below.

|                |    |       |    |    |    |    |    |                        |    |    |    |              |    |                 |    |           |    |    |    |                |    |   |   |   |   |   |   |   |   |   |   |
|----------------|----|-------|----|----|----|----|----|------------------------|----|----|----|--------------|----|-----------------|----|-----------|----|----|----|----------------|----|---|---|---|---|---|---|---|---|---|---|
| 31             | 30 | 29    | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19           | 18 | 17              | 16 | 15        | 14 | 13 | 12 | 11             | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 22 |    |       |    |    |    |    |    | Packet Size = 32 bytes |    |    |    |              |    |                 |    | Entity ID |    |    |    |                |    |   |   |   |   |   |   |   |   |   |   |
| *1             | *2 | Spare |    |    |    |    |    | Red Component          |    |    |    |              |    | Green Component |    |           |    |    |    | Blue Component |    |   |   |   |   |   |   |   |   |   |   |
| X Scale        |    |       |    |    |    |    |    |                        |    |    |    | Y Scale      |    |                 |    |           |    |    |    |                |    |   |   |   |   |   |   |   |   |   |   |
| Z Scale        |    |       |    |    |    |    |    |                        |    |    |    | Time Scale   |    |                 |    |           |    |    |    |                |    |   |   |   |   |   |   |   |   |   |   |
| Spare          |    |       |    |    |    |    |    |                        |    |    |    | Effect Count |    |                 |    |           |    |    |    |                |    |   |   |   |   |   |   |   |   |   |   |
| Separation     |    |       |    |    |    |    |    |                        |    |    |    |              |    |                 |    |           |    |    |    |                |    |   |   |   |   |   |   |   |   |   |   |
| Burst Interval |    |       |    |    |    |    |    |                        |    |    |    |              |    |                 |    |           |    |    |    |                |    |   |   |   |   |   |   |   |   |   |   |
| Duration       |    |       |    |    |    |    |    |                        |    |    |    |              |    |                 |    |           |    |    |    |                |    |   |   |   |   |   |   |   |   |   |   |

- \*1 Sequence Direction
- \*2 Color Enable

Special Effect Definition Parameter Definitions:

| Formats and Ranges   | Description   |
|--|---|
| Packet ID = 22 : unsigned char : N/A   | This parameter identifies this data packet as the Special Effect Definition data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique special effect definition should only be specified once per frame. If more than one data packet with the same Entity ID is received in the same frame, the last one received will be used. |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.   |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A                  | This parameter indicates which effect is being modified. The Entity ID must correspond to a previously assigned entity. If this data packet is sent without a previously defined Entity ID either earlier in the same Ethernet message or in an earlier Ethernet message, an error will be generated and this data packet will be ignored.                                |
| Sequence Direction : Boolean : N/A<br><br>Valid Values:<br><br>0 = Forward<br>1 = Backward<br><br>Default: 0 | This parameter indicates whether the effect animation sequence should be sequence from beginning to end or vice versa.  |

|   |   |
|---|---|
| <p>Color Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Off<br/>1 = On</p> <p>Default: 0</p>  | <p>This parameter indicates whether the Red, Green, and Blue color values specified in this data packet will be applied to the special effect.</p>  |
| <p>Red color value : unsigned char : N/A</p> <p>Valid Values:</p> <p>0 – 255</p> <p>Default: 255</p>  | <p>This parameter specifies the red component of a color to be applied to the effect. The color will be combined with the effect's original color.</p> <p>If the Color Enable parameter is set to 0 (Disabled), this parameter will be ignored and the color of the effect will be as modeled.</p>    |
| <p>Green color value : unsigned char : N/A</p> <p>Valid Values:</p> <p>0 – 255</p> <p>Default: 255</p>  | <p>This parameter specifies the green component of a color to be applied to the effect. The color will be combined with the effect's original color.</p> <p>If the Color Enable parameter is set to 0 (Disabled), this parameter will be ignored and the color of the effect will be as modeled.</p>  |
| <p>Blue color value : unsigned char : N/A</p> <p>Valid Values:</p> <p>0 – 255</p> <p>Default: 255</p>   | <p>This parameter specifies the blue component of a color to be applied to the effect. The color will be combined with the effect's original color.</p> <p>If the Color Enable parameter is set to 0 (Disabled), this parameter will be ignored and the color of the effect will be as modeled.</p>   |
| <p>X Scale : scaled distance format (16 bit B6): N/A</p> <p>Valid Values:</p> <p>limits of scaled distance format (16 bit B6)</p> <p>Default: 1.0</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies a scale factor to apply along the effect's X axis. A value of 1.0 indicates that no scale should be applied. A value greater than 1.0 will cause the effect to be stretched along the axis. A value less than 1.0 will cause the effect to be reduced along the axis.</p> |
| <p>Y Scale : scaled distance format (16 bit B6): N/A</p> <p>Valid Values:</p> <p>limits of scaled distance format (16 bit B6)</p> <p>Default: 1.0</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies a scale factor to apply along the effect's Y axis. A value of 1.0 indicates that no scale should be applied. A value greater than 1.0 will cause the effect to be stretched along the axis. A value less than 1.0 will cause the effect to be reduced along the axis.</p> |
| <p>Z Scale : scaled distance format (16 bit B6): N/A</p> <p>Valid Values:</p> <p>limits of scaled distance format (16 bit B6)</p> <p>Default: 1.0</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies a scale factor to apply along the effect's Z axis. A value of 1.0 indicates that no scale should be applied. A value greater than 1.0 will cause the effect to be stretched along the axis. A value less than 1.0 will cause the effect to be reduced along the axis.</p> |

|   |  |
|---|--|
| <p>Time Scale : scaled distance format (16 bit B6): N/A</p> <p>Valid Values:</p> <p>    limits of scaled distance format (16 bit B6)</p> <p>Default: 1.0</p>                            | <p>This parameter specifies a scale factor to apply to the time period for the effect's animation sequence. A value of 1.0 indicates that no scale should be applied. A value greater than 1.0 will cause the overall period to increase, causing the effect animation to play at a slower speed. A value less than 1.0 will decrease the period, causing the effect animation to play at an increased rate.</p> <p>Note: This parameter does not affect the duration of the effect unless the Duration parameter is set to 0. For example, if Time Scale is set to a value greater than 1.0 and the Duration parameter is set to 3.0, the effect will play for exactly three seconds and disappear even if the animation has not yet played through its entire sequence.</p>  |
| <p>Effect Count : unsigned short : N/A</p> <p>Valid Values:</p> <p>    0 = ignore</p> <p>    1 to Maximum allowed by data format</p> <p>Default: Specified by IG Configuration</p>      | <p>This parameter indicates how many effects are contained within a single burst. This allows the host to initiate a certain number of repetitions of an effect using a single data packet. This feature may be useful for rendering gun flashes, for example; the Host could specify that 15 rounds would be fired from a particular weapon where each firing would be represented by a gun flash effect. Rather than submit 15 data packets to control those flashes, a single data packet with this field set to 15 would achieve the same result.</p> <p>The Host may control the frequency of the bursts by setting the Burst Interval field of this data packet to an appropriate value.</p> <p>This parameter may also be used to set the number of particles in a particulate debris effect.</p> <p>Note: This parameter was named "Burst Count" in version 2.0 of this document. Its use has remained the same.</p> |
| <p>Separation : float IEEE: meters</p> <p>Valid Values:</p> <p>    0 = ignore</p> <p>    &gt;0 to Maximum allowed by data format</p> <p>Default: Specified by IG Configuration</p>      | <p>This parameter indicates the distance between particles within a burst when the Burst Count parameter of this data packet is greater than zero.</p>   |
| <p>Burst Interval : float IEEE: seconds</p> <p>Valid Values:</p> <p>    0 = ignore</p> <p>    &gt;0 to Maximum allowed by data format</p> <p>Default: Specified by IG Configuration</p> | <p>This parameter indicates the time between successive bursts when the Effect Count parameter of this data packet is greater than zero. The interval is measured from the start of one burst to the start of the next.</p> <p>Note: This parameter was named "Burst Rate" in version 2.0 of this document. Its use has remained the same.</p>   |

Duration : float IEEE : second

Valid Values:

- 1 = always on
- 0 = using default
- >0 to Maximum allowed by data format


Default: Specified by IG Configuration

This parameter indicates how long an effect or sequence of bursts will be active. If an effect has a non-negative duration the effect will automatically be disabled after the duration elapses.




**5.3.12 View Definition**

The View Definition data packet is contained in the Ethernet message sent from the Host to the IG. It is used to define the characteristics of a view and/or override the IG default configuration.




**Figure 24 – View Definition Nomenclature**

Specifying 0 (None) in the View Group parameter allows for the definition of an individual view. Figure 25 shows three individual views defined using three instances of the View Definition data packet. Each instance would have a unique value in the View ID parameter, and each View Group parameter would be set to 0 (None).




**Figure 25 – Individual Definitions for Three Views**

Individual views may be grouped together as shown in Figure 26 by using the View Group parameter. In this way, several views can be moved in unison through the use of a single View Control data packet. To do this, two or more View Definition packets will be used to assign individual views to the same view group. Each View Definition packet will contain the same value in the View Group parameter.



**Figure 26 – A Group of Three Individual Views**

If the View Group parameter is set to 0 (None) and the View ID parameter corresponds to a view that is a member of a view group, that view will be separated from the group as shown in Figure 27.



**Figure 27 – View Separated from a View Group**

The contents of the View Definition data packet are shown below.

|                |    |    |    |    |     |     |       |                        |    |    |    |    |    |    |    |                      |    |    |    |    |    |    |   |    |   |    |   |   |   |   |   |
|----------------|----|----|----|----|-----|-----|-------|------------------------|----|----|----|----|----|----|----|----------------------|----|----|----|----|----|----|---|----|---|----|---|---|---|---|---|
| 31             | 30 | 29 | 28 | 27 | 26  | 25  | 24    | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15                   | 14 | 13 | 12 | 11 | 10 | 9  | 8 | 7  | 6 | 5  | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 23 |    |    |    |    |     |     |       | Packet Size = 32 bytes |    |    |    |    |    |    |    | View ID              |    |    |    | *1 |    | *2 |   | *3 |   | *4 |   |   |   |   |   |
| *5             | *6 | *7 | *8 | *9 | *10 | *11 | Spare |                        |    |    |    |    |    |    |    |                      |    |    |    |    |    |    |   |    |   |    |   |   |   |   |   |
|                |    |    |    |    |     |     |       |                        |    |    |    |    |    |    |    | Field of View Near   |    |    |    |    |    |    |   |    |   |    |   |   |   |   |   |
|                |    |    |    |    |     |     |       |                        |    |    |    |    |    |    |    | Field of View Far    |    |    |    |    |    |    |   |    |   |    |   |   |   |   |   |
|                |    |    |    |    |     |     |       |                        |    |    |    |    |    |    |    | Field of View Left   |    |    |    |    |    |    |   |    |   |    |   |   |   |   |   |
|                |    |    |    |    |     |     |       |                        |    |    |    |    |    |    |    | Field of View Right  |    |    |    |    |    |    |   |    |   |    |   |   |   |   |   |
|                |    |    |    |    |     |     |       |                        |    |    |    |    |    |    |    | Field of View Top    |    |    |    |    |    |    |   |    |   |    |   |   |   |   |   |
|                |    |    |    |    |     |     |       |                        |    |    |    |    |    |    |    | Field of View Bottom |    |    |    |    |    |    |   |    |   |    |   |   |   |   |   |

- \*1 View Group
- \*2 View Type
- \*3 Pixel Replication Mode
- \*4 Mirror Mode
- \*5 Tracker Assign
- \*6 Field of View Near Enable
- \*7 Field of View Far Enable
- \*8 Field of View Left Enable
- \*9 Field of View Right Enable
- \*10 Field of View Top Enable
- \*11 Field of View Bottom Enable

View Definition Parameter Definitions:

| Formats and Ranges   | Description   |
|--|---|
| Packet ID = 23 : unsigned char : N/A   | <p>This parameter identifies this data packet as a View Definition data packet.</p> <p>There can be multiple instances of this data packet per frame, but each unique view definition should only be specified once per frame. If more than one data packet with the same View Group Assignment and/or a View ID is received in the same frame, the last one received will be used.</p> |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.   |
| <p>View ID: 5 bit field: N/A</p> <p>Valid Values:</p> <p>0 – 31 View ID</p> <p>Default: N/A</p>                        | <p>This parameter specifies the view to which this packet should be applied.</p> <p>If the Host requests a view that has not been configured on the IG, an error will be generated and the data packet will be disregarded.</p>   |
| <p>View Group: 3 bit field: N/A</p> <p>Valid Values:</p> <p>0 = none</p> <p>1 – 7 Group select</p> <p>Default: N/A</p> | <p>This parameter specifies the view group to which the view is to be assigned. When this parameter is set to 0 (None), the view specified by the View ID field is separated from whatever group it was assigned, if any.</p> <p>The host may assign up to 32 views to a single group by sending a separate View Definition packet for each.</p>  |

|  |  |
|--|--|
| View Type: 3 bit field: N/A  | This parameter specifies the view type.  |
| Valid Values:<br><br>0 – 7   | The integration engineer should consult the image generator configuration to determine what types of views are available and what their View Type assignments should be.   |
| Default: Specified by IG Configuration   |  |
| Pixel Replication: 3 bit field: N/A  | This parameter specifies what pixel replication function should be applied to the view. This function is typically used in particular sensor applications to perform electronic zoom (pixel and line doubling function). |
| Valid Values:<br><br>0 = No Replicate<br>1 = 1x2 Pixel Replicate<br>2 = 2x1 Pixel Replicate<br>3 = 2x2 Pixel Replicate<br>4 = TBD<br>5 = TBD<br>6 = TBD<br>7 = TBD |  |
| Default: Specified by IG Configuration   |  |
| View Mirror: 2 bit field: N/A  | This parameter specifies what mirroring functions should be applied to the view. This function is typically used to replicate the view of a mirrored surface used in display systems or rear view mirrors.               |
| Valid Values:<br><br>0 = None<br>1 = Horizontal<br>2 = Vertical<br>3 = Horizontal and Vertical   |  |
| Default: Specified by IG Configuration   |  |
| Tracker Assign: 1 bit field: N/A   | This parameter specifies whether the view should be controlled by an external tracking device.   |
| Valid Values:<br><br>0 = Not Assigned<br>1 = Assigned  |  |
| Default: Specified by IG Configuration   |  |
| Field of View Near Enable : Boolean : N/A  | This parameter identifies whether the Field of View Near value contained in this data packet is manipulated from the Host, i.e. Enabled, or not manipulated by the Host, i.e. Disabled.                                  |
| Valid Values:<br><br>0 = Disable<br>1 = Enable   |  |
| Default: Specified by IG Configuration   |  |

|   |  |
|---|--|
| <p>Field of View Far Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>  | <p>This parameter identifies whether the Field of View Far value contained in this data packet is manipulated from the Host, i.e. Enabled, or not manipulated by the Host, i.e. Disabled.</p>                      |
| <p>Field of View Left Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>   | <p>This parameter identifies whether the Field of View Left value contained in this data packet is manipulated from the Host, i.e. Enabled, or not manipulated by the Host, i.e. Disabled.</p>                     |
| <p>Field of View Right Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>  | <p>This parameter identifies whether the Field of View Right contained in this data packet is manipulated from the Host, i.e. Enabled, or not manipulated by the Host, i.e. Disabled.</p>                          |
| <p>Field of View Top Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>  | <p>This parameter identifies whether the Field of View Top contained in this data packet is manipulated from the Host, i.e. Enabled, or not manipulated by the Host, i.e. Disabled.</p>                            |
| <p>Field of View Bottom Enable : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = Disable<br/>1 = Enable</p> <p>Default: N/A</p>   | <p>This parameter identifies whether the Field of View Bottom value contained in this data packet is manipulated from the Host, i.e. Enabled, or not manipulated by the Host, i.e. Disabled.</p>                   |
| <p>Field of View Near: Float IEEE : meters</p> <p>Valid values:</p> <p>&gt;0 to maximum allowed by the data format</p> <p>Default: Specified by IG Configuration<br/>Datum: View Reference Point (see Figure 24).</p> | <p>This parameter is used to define the near clipping plane for the view. Any object inside of this distance will be clipped from the view. It should be noted that 0 and negative numbers are invalid values.</p> |


|   |   |
|---|---|
| <p>Field of View Far: Float IEEE : meters</p> <p>Valid Values:</p> <p>&gt;Field of View Near to maximum allowed by the data format</p> <p>Default: Specified by IG Configuration<br/>Datum: View Reference Point (see Figure 24).</p> | <p>This parameter is used to define the far clipping plane for the view. Any object outside of this distance will be clipped from the view. This value must be a positive number greater than the Field of View Near value. It should be noted that 0 is not a valid value.</p> |
| <p>Field of View Left : Float IEEE : degrees</p> <p>Valid Values:</p> <p>&gt;-180.0 to 180.0</p> <p>Default: Specified by IG Configuration<br/>Datum: View Reference Point (see Figure 24).</p>                                       | <p>This parameter is used to define the size of the left side of the field of view. This value should always be less than the Field of View Right. If this condition is not satisfied, an error will be generated and the data packet will be disregarded.</p>                  |
| <p>Field of View Right: Float IEEE : degrees</p> <p>Valid Values:</p> <p>&gt;-180.0 to 180.0</p> <p>Default: Specified by IG Configuration<br/>Datum: View Reference Point (see Figure 24).</p>                                       | <p>This parameter is used to define the size of the right side of the field of view. This value should always be greater than the Field of View Left value. If this condition is not satisfied, an error will be generated and the data packet will be disregarded.</p>         |
| <p>Field of View Top: Float IEEE : degrees</p> <p>Valid Values:</p> <p>&gt;-180.0 to 180.0</p> <p>Default: Specified by IG Configuration<br/>Datum: View Reference Point (see Figure 24).</p>   | <p>This parameter is used to define the size of the top side of the field of view. This value should always be greater than the Field of View Bottom value. If this condition is not satisfied, an error will be generated and the data packet will be disregarded.</p>         |
| <p>Field of View Bottom: Float IEEE : degrees</p> <p>Valid Values:</p> <p>&gt; -180.0 to 180.0</p> <p>Default: Specified by IG Configuration<br/>Datum: View Reference Point (see Figure 24).</p>                                     | <p>This parameter is used to define the size of the bottom side of the field of view. This value should always be less than the Field of View Top value. If this condition is not satisfied, an error will be generated and the data packet will be disregarded.</p>            |

### 5.3.13 Collision Detection Segment Definition

The Collision Detection Segment Definition data packet is contained in the Ethernet message sent from the Host to the IG. This data packet is used to define a segment along which collision testing will be performed on the IG. During each computational frame, the IG will test each collision segment to determine if it intersects a polygon. If an intersection occurs, the IG notifies the host via a Collision Detection Segment Response packet (see Section 5.4.4). Since collision tests are conducted at discrete moments in time, it is possible that a segment could pass completely through a polygon between successive tests, causing a missed collision. It may, therefore, be necessary for the IG to use segment sweeping or some other mechanism to avoid this situation.

The Entity ID parameter is used to associate a collision detection segment with a particular entity instance. Multiple segments may be defined for a given entity; each segment defined for the entity is further identified by the Segment ID parameter. When a collision is detected along a segment, the IG will send a Collision Detection Segment Response packet containing the corresponding Entity ID and Segment ID parameters. Note that collision detection segment testing should not occur between segments and polygons belonging to the same entity.

The collision mask field is used to specify which materials are to be included in the IG's collision detection processing. This provides the ability to include certain features such as terrain, buildings, trees, etc. for consideration for collision detection while excluding other features such as clouds, smoke, dust, etc. When a collision is detected between objects of materials enabled by the collision mask, the Material Type field contained within the resulting Collision Detection Segment Response packet will contain a subtype for that feature. For example, if terrain is to be included in collision testing, a collision detection response might indicate that the intersection was with concrete, grass, rock, asphalt, etc.



The Collision Detection Segment Definition data packet is used to establish segments that will be tested for contact with polygonal surfaces. The segments are described with start and end points within the entity's reference system. In this example, there are five test segments as follows: Segment 1 will test the length of the fuselage, segment 2 will test the vertical height of the fuselage at the cockpit area, segment 3 will test the wingspan, segments 4 and 5 will test the right and left vertical stabilizers, respectively.

**Figure 28 – Collision Detection Segment Definition**

The contents of the Collision Detection Segment Definition data packet are shown below.

|                 |            |    |    |    |    |    |    |                        |    |    |                 |    |    |    |    |           |    |    |       |    |    |   |   |   |   |   |   |   |   |   |   |
|-----------------|------------|----|----|----|----|----|----|------------------------|----|----|-----------------|----|----|----|----|-----------|----|----|-------|----|----|---|---|---|---|---|---|---|---|---|---|
| 31              | 30         | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20              | 19 | 18 | 17 | 16 | 15        | 14 | 13 | 12    | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 24  |            |    |    |    |    |    |    | Packet Size = 24 bytes |    |    |                 |    |    |    |    | Entity ID |    |    |       |    |    |   |   |   |   |   |   |   |   |   |   |
| *1              | Segment ID |    |    |    |    |    |    | Collision Mask         |    |    |                 |    |    |    |    |           |    |    | Spare |    |    |   |   |   |   |   |   |   |   |   |   |
| Segment X Start |            |    |    |    |    |    |    |                        |    |    | Segment Y Start |    |    |    |    |           |    |    |       |    |    |   |   |   |   |   |   |   |   |   |   |
| Segment Z Start |            |    |    |    |    |    |    |                        |    |    | Segment X End   |    |    |    |    |           |    |    |       |    |    |   |   |   |   |   |   |   |   |   |   |
| Segment Y End   |            |    |    |    |    |    |    |                        |    |    | Segment Z End   |    |    |    |    |           |    |    |       |    |    |   |   |   |   |   |   |   |   |   |   |

\*1 Segment Enable

Collision Detection Segment Definition Parameter Definitions:

| Formats and Ranges   | Description  |
|--|--|
| Packet ID = 24 : unsigned char : N/A   | This parameter identifies this data packet as the Collision Detection Segment Definition data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique collision detection segment definition should only be specified once per frame. If more than one data packet with the same Entity ID and Segment ID is received in the same frame, the last one received will be used. |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.  |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A                | This parameter indicates the entity to which this collision detection definition is assigned. An entity must have been previously created having the specified ID. If this segment is applied to a non-existent entity, an error will be generated and this data packet will be ignored. The entity may be defined earlier in the same Ethernet message or in an earlier Ethernet message.                         |
| Segment Enable : Boolean : N/A<br><br>Valid Values:<br><br>0 = Disabled<br>1 = Enabled<br><br>Default: N/A | This parameter indicates whether the defined segment is enabled for collision testing.   |
| Segment ID : 7 bit field : N/A<br><br>Valid Values:<br><br>0 to 127<br><br>Default: N/A                    | This parameter indicates which segment is being uniquely defined for the given entity. The range 0 through 127 can be reused per entity.   |



|  |   |
|--|---|
| <p>Collision Mask : 32-bit word : N/A</p> <p>Valid Values:</p> <p>See the Collision Mask assignments in the applicable Database, Entity Attribute and IG Functions Definition Document (s).</p> <p>Default: N/A</p>    | <p>This parameter indicates which environment features will be included in or excluded from consideration for collision detection testing. Each bit represents a specific feature.</p>            |
| <p>Segment X Start : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the starting point of the collision segment in the X-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p> |
| <p>Segment Y Start : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the starting point of the collision segment in the Y-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p> |
| <p>Segment Z Start : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the starting point of the collision segment in the Z-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p> |
| <p>Segment X End : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p>   | <p>This parameter specifies the ending point of the collision segment in the X-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p>   |
| <p>Segment Y End : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p>   | <p>This parameter specifies the ending point of the collision segment in the Y-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p>   |

Segment Z End : scaled distance format (16 bit B6):  
meters

Valid Values:

limits of scaled distance format (16 bit B6)

Default: N/A

Datum: Entity coordinate system, see Figure 9.


This parameter specifies the ending point of the collision segment in the Z-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.

### 5.3.14 Collision Detection Volume Definition

The Collision Detection Volume Definition data packet is contained in the Ethernet message sent from the Host to the IG. This data packet is used to define a volume through which collision testing will be performed on the IG. During each computational frame, the IG will perform collision tests between collision detection volumes. If an intersection occurs, the IG notifies the host via a Collision Detection Volume Response packet (see Section 5.4.7). Since collision tests are conducted at discrete moments in time, it is possible that two entities could pass through one another between successive tests, causing a missed collision. It may, therefore, be necessary for the IG to use volume sweeping or some other mechanism to avoid this situation.

The Collision Detection Volume Definition packet is used to define a volume around a centroid within which collision testing will be performed. This volume is referenced to a particular entity specified by the Entity ID parameter. If more precise collision areas are required, the volume can be reduced in size to accommodate refined collision detections. All enabled volumes will be tested for intersection against other volumes not associated with the given entity.

To match collision volume definitions with responses from the IG, the Volume ID parameter is used. The same value will be returned in the Volume ID parameter of the corresponding Collision Detection Volume Response data packet to uniquely identify the response. Each volume must be assigned a unique ID per entity. Thus, a Volume ID of zero, one, two, etc., can be assigned to every entity if desired.



The Swept Volume Collision Detection Definition data packet is used to establish the volume to be checked for collisions. The volumes are described by Height, Width, and Depth oriented to the entity's reference system and centered about a common centroid. The centroid of the volume is positioned relative to the entity's reference point. In this example, the aft volume has a centroid that is coincident with the entity's reference point. The forward volume is positioned using a vector referenced from the entity's reference point. The Volume Centroid X, Y, and Z Offsets define this vector.

**Figure 29 – Collision volume definition**

The contents of the Collision Detection Volume Definition data packet are shown below.

|                   |           |    |    |    |    |    |    |                        |    |                   |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|-------------------|-----------|----|----|----|----|----|----|------------------------|----|-------------------|----|----|----|----|----|-----------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31                | 30        | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21                | 20 | 19 | 18 | 17 | 16 | 15        | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 25    |           |    |    |    |    |    |    | Packet Size = 20 bytes |    |                   |    |    |    |    |    | Entity ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| *1                | Volume ID |    |    |    |    |    |    | Spare                  |    |                   |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Centroid X Offset |           |    |    |    |    |    |    |                        |    | Centroid Y Offset |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Centroid Z Offset |           |    |    |    |    |    |    |                        |    | Height            |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Width             |           |    |    |    |    |    |    |                        |    | Depth             |    |    |    |    |    |           |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

\*1 Volume Enable

Collision Detection Volume Definition Parameter Definitions:

| Formats and Ranges  | Description   |
|---|---|
| Packet ID = 25 : unsigned char : N/A  | This parameter identifies this data packet as the Collision Detection Volume Definition data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique swept volume collision definition should only be specified once per frame. If more than one data packet with the same Entity ID and Volume ID is received in the same frame, the last one received will be used. |
| Packet Size : unsigned char : N/A   | This parameter indicates the number of bytes in this data packet.   |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A               | This parameter indicates the entity to which this collision detection definition is assigned. An entity must have been previously created with the Entity ID. If this volume is applied to a non-existent entity, an error will be generated and this data packet will be ignored. The entity may be defined earlier in the same Ethernet message or in an earlier Ethernet message.                        |
| Volume Enable : Boolean : N/A<br><br>Valid Values:<br><br>0 = Disabled<br>1 = Enabled<br><br>Default: N/A | This parameter indicates whether the defined volume is enabled for collision testing.   |
| Volume ID : 7 bit field : N/A<br><br>Valid Values:<br><br>0 to 127<br><br>Default: N/A                    | This parameter indicates which volume is being uniquely defined for a given entity. The range of Volume ID 0 through 127 can be reused per entity.  |

|  |  |
|--|--|
| <p>Centroid X Offset : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>    limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the offset of the volume's centroid along the X-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p>     |
| <p>Centroid Y Offset : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>    limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the offset of the volume's centroid along the Y-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p>     |
| <p>Centroid Z Offset : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>    limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the offset of the volume's centroid along the Z-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p>     |
| <p>Height : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>    limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p>            | <p>This parameter specifies the height of the volume. The height is along the Z-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p> |
| <p>Width : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>    limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p>             | <p>This parameter specifies the width of the volume. The width is along the Y-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p>   |
| <p>Depth : scaled distance format (16 bit B6): meters</p> <p>Valid Values:</p> <p>    limits of scaled distance format (16 bit B6)</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p>             | <p>This parameter specifies the depth of the volume. The depth is along the X-axis with respect to the entity's reference point. See Section 2.4.2.2 for a description of the data format.</p>   |

### 5.3.15 Height Above Terrain Request

The Height Above Terrain Request data packet is contained in the Ethernet message sent from the Host to the IG. It is used to request the height above terrain (HAT) at a specified location. If HAT is required for an entity, the host should insert the positional information for that entity in this data packet. To match up requests from the host with responses from the IG, the HAT ID parameter is used. The same value will be returned in the HAT ID parameter of the corresponding Height Above Terrain Response data packet described in section 5.4.2 to uniquely identify the response. The HAT ID value should be manipulated in such a way as to not duplicate the value in a reasonable amount of time (e.g., one second). This will prevent similarly identified requests from being lost by the IG.

There is no restriction on the number of HAT requests that can be made in a single frame. The user should be aware however that the response time of the IG might be degraded under conditions that overload the IG HAT computation mechanism.

The IG will only return valid HAT data for points within the bounds of the database being displayed. If a point beyond the database bounds is requested, an invalid answer will be returned in the Height Above Terrain Response data packet. Refer to the applicable Database and Entity Attribute Definition Document(s) for details on the database bounds.

The contents of the Height Above Terrain Request data packet are shown below.

|                 |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|-----------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|--------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31              | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15     | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 41  |    |    |    |    |    |    |    | Packet Size = 32 bytes |    |    |    |    |    |    |    | HAT ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Spare           |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Altitude (MSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Altitude (LSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Latitude (MSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Latitude (LSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Longitude (MSW) |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Longitude (LSW) |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

Height Above Terrain Point Request Parameter Definitions:

| Formats and Ranges   | Description   |
|--|---|
| Packet ID = 41 : unsigned char : N/A   | This parameter identifies this data packet as a Height Above Terrain Request data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique HAT request should only be specified once per frame. If more than one data packet with the same HAT ID is received in the same frame, the last one received will be used. |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.   |
| HAT ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A | This parameter is used to identify the HAT request so that when the corresponding Height Above Terrain Response data packet is returned, it can be identified by the host.  |

|   |  |
|---|--|
| Altitude : Double IEEE : meters   | This parameter specifies the Altitude from which the HAT request is being made.              |
| Valid Values:<br><br>Minimum to maximum allowed by the data format          |  |
| Default: N/A<br>Datum: Mean Sea Level                                       |  |
| Latitude : Double IEEE : degrees  | This parameter specifies the latitudinal position from which the HAT request is being made.  |
| Valid Values:<br><br>0 to +90 (north positive)<br>0 to -90 (south negative) |  |
| Default: N/A<br>Datum: Equator  |  |
| Longitude : Double IEEE : degrees   | This parameter specifies the longitudinal position from which the HAT request is being made. |
| Valid Values:<br><br>0 to +180 (east positive)<br>0 to -180 (west negative) |  |
| Default: N/A<br>Datum: Prime Meridian                                       |  |

### 5.3.16 Line of Sight Occult Request

The Line of Sight Occult Request data packet is contained in the Ethernet message sent from the Host to the IG. It is used to determine intervisibility or occulting between a source and destination point. The result of the LOS Occult test is contained in the Line of Sight Response data packet, described in section 5.4.3.

To match up requests from the host with responses from the IG, the LOS ID parameter is used. The same value will be returned in the LOS ID parameter of the corresponding Line of Sight data packet to uniquely identify the response. The LOS ID value should be manipulated each frame in such a way as to not duplicate the value in a reasonable amount of time (e.g., one second). This will prevent similarly identified requests from being lost by the IG. Note that Line of Sight Occult Request packets and Line of Sight Range Request packets share the LOS ID parameter; duplicating the LOS ID value between both request types can also cause data loss.

The user should be aware that if the source or destination points of the line of sight occult request emanate from or terminate within an entity with geometry, a valid occult response would be invoked. In other words, if an endpoint is enclosed within a model, the IG will return a response with the line-of-sight intersection placed somewhere on the model's geometry. The host should, therefore, adjust the positions of the source and destination points so that they are just beyond the entities' geometry.

There is no restriction on the number of LOS requests that can be sent in a single frame. The user should be aware, however, that the response time of the IG might be degraded under conditions that overload the IG LOS computation mechanism.

Valid LOS responses will only be returned for locations on the current database. Refer to the applicable Database and Entity Attribute Definition Document (s) for details on the extent of the Database.

The contents of the Line of Sight Occult Request data packet are shown below.

| 31                          | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15     | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-----------------------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|--------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| Packet ID = 42              |    |    |    |    |    |    |    | Packet Size = 56 bytes |    |    |    |    |    |    |    | LOS ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Spare                       |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Altitude (MSW)       |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Altitude (LSW)       |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Latitude (MSW)       |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Latitude (LSW)       |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Longitude (MSW)      |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Longitude (LSW)      |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Destination Altitude (MSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Destination Altitude (LSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Destination Latitude (MSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Destination Latitude (LSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Destination Longitude (MSW) |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Destination Longitude (LSW) |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

Line of Sight Occult Request Parameter Definitions:

| Formats and Ranges                   | Description  |
|--------------------------------------|--|
| Packet ID = 42 : unsigned char : N/A | <p>This parameter identifies this data packet as a Line of Sight Occult Request data packet.</p> <p>There can be multiple instances of this data packet per frame, but each unique LOS request should only be specified once per frame. If more than one data packet with the same LOS ID is received in the same frame, the last one received will be used.</p> |



|  |  |
|--|--|
| <p>Packet Size : unsigned char : N/A</p>   | <p>This parameter indicates the number of bytes in this data packet.</p>   |
| <p>LOS ID : unsigned short : N/A</p> <p>Valid Values:</p> <p>0 to 65535</p> <p>Default: N/A</p>  | <p>This parameter is used to identify the LOS request so that when the response to the request is returned it can be identified by the host. This is done via the LOS ID parameter of the Line of Sight Response data packet.</p> <p>Because the Line-of-Sight Response data packet is used for responding to both the LOS Occult and LOS Range requests, the LOS ID parameters assigned for these queries should be unique between the two request types.</p> |
| <p>Source Altitude : Double IEEE : meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: N/A</p> <p>Datum: Mean Sea Level</p>                   | <p>This parameter specifies the altitude of the source point for the LOS request segment.</p>  |
| <p>Source Latitude: Double IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +90 (north positive)</p> <p>0 to -90 (south negative)</p> <p>Default: N/A</p> <p>Datum: Prime Meridian</p>      | <p>This parameter specifies the latitudinal position of the source point for the LOS request segment.</p>  |
| <p>Source Longitude: Double IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +180 (east positive)</p> <p>0 to -180 (west negative)</p> <p>Default: N/A</p> <p>Datum: Prime Meridian</p>     | <p>This parameter specifies the longitudinal position of the source point for the LOS request segment.</p>   |
| <p>Destination Altitude: Double IEEE : meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: N/A</p> <p>Datum: Mean Sea Level</p>               | <p>This parameter specifies the altitude of the destination point for the LOS request segment.</p>   |
| <p>Destination Latitude: Double IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +90 (north positive)</p> <p>0 to -90 (south negative)</p> <p>Default: N/A</p> <p>Datum: Prime Meridian</p> | <p>This parameter specifies the latitudinal position of the destination point for the LOS request segment.</p>   |

Destination Longitude: Double IEEE : degrees

This parameter specifies the longitudinal position of the destination point for the LOS request segment.

Valid Values:

- 0 to +180 (east positive)
- 0 to -180 (west negative)

Default: N/A

Datum: Prime Meridian

**5.3.17 Line of Sight Range Request**

The Line of Sight Range Request data packet is contained in the Ethernet message sent from the Host to the IG. It is used to determine the range from a source point to an object within the environment. The Line of Sight test vector emanates from the source position specified in this data packet. A minimum and a maximum range are specified in order to constrain the search, if desired. The result to the LOS Range test is contained in the Line of Sight Response data packet, described in section 5.4.3. To match up requests from the host with responses from the IG, the LOS ID parameter is used. The same value will be returned in the LOS ID parameter of the corresponding Line of Sight Response data packet to uniquely identify the response. The LOS ID value should be manipulated in such a way as to not duplicate the value in a reasonable amount of time (e.g., one second). This will prevent similarly identified requests from being lost by the IG. Note that Line of Sight Occult Request packets and Line of Sight Range Request packets share the LOS ID parameter; duplicating the LOS ID value between both request types can also cause data loss.

There is no restriction on the number of LOS requests that can be sent in a single frame. The user should be aware, however, that the response time of the IG might be degraded under conditions that overload the IG LOS computation mechanism.

The IG will only return valid LOS data if an intersection is detected within the active LOS segment, that is, between the minimum and maximum distances as specified in this data packet, and the request is located within the bounds of the current database. Refer to the applicable Database and Entity Attribute Definition Document(s) for details on the extent of the database.

The contents of the Line of Sight Range Request data packet are shown below.

|                        |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|------------------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|--------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31                     | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15     | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 43         |    |    |    |    |    |    |    | Packet Size = 48 bytes |    |    |    |    |    |    |    | LOS ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Azimuth                |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Elevation              |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Spare                  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Minimum Range          |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Maximum Range          |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Altitude (MSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Altitude (LSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Latitude (MSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Latitude (LSW)  |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Longitude (MSW) |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Source Longitude (LSW) |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

Line of Sight Range Request Parameter Definitions:

| Formats and Ranges                   | Description  |
|--------------------------------------|--|
| Packet ID = 43 : unsigned char : N/A | This parameter identifies this data packet as a Line of Sight Range Request data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique LOS request should only be specified once per frame. If more than one data packet with the same LOS ID is received in the same frame, the last one received will be used. |
| Packet Size : unsigned char : N/A    | This parameter indicates the number of bytes in this data packet.  |

|  |  |
|--|--|
| <p>LOS ID : unsigned short : N/A</p> <p>Valid Values:</p> <p>0 to 65535</p> <p>Default: N/A</p>  | <p>This parameter is used to identify the LOS request so that when the answer to the request is returned it can be identified by the host. This is done via the LOS ID parameter of the Line of Sight Response data packet.</p> <p>Because the Line-of-Sight Response data packet is used for responding to both the LOS Occult and LOS Range requests, the LOS ID parameters assigned for these queries should be unique between the two request types.</p> |
| <p>Azimuth : Float IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +360 clockwise</p> <p>Default: N/A</p> <p>Datum: True North.</p>  | <p>This parameter specifies the azimuth of the LOS vector.</p> <p>Note: This parameter was named “LOS Request Heading” in version 2.0 of this document. Its use has remained the same.</p>   |
| <p>Elevation : Float IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +90 up<br/>0 to -90 down</p> <p>Default: N/A</p> <p>Datum: see Figure 7.</p>                                      | <p>This parameter specifies the elevation of the LOS vector.</p> <p>Note: This parameter was named “LOS Request Pitch” in version 2.0 of this document. Its use has remained the same.</p>   |
| <p>Minimum Range : Float IEEE : meters</p> <p>Valid Values:</p> <p>0.0 to &lt; LOS Request Maximum Distance</p> <p>Default: N/A</p>  | <p>This parameter specifies the distance from the source position specified in this data packet to a point along the LOS vector where intersection testing will begin.</p>   |
| <p>Maximum Range : Float IEEE : meters</p> <p>Valid Values:</p> <p>&gt; LOS Request Minimum Distance to maximum allowed by the data format</p> <p>Default: N/A</p>                     | <p>This parameter specifies the maximum extent from the source position specified in this data packet to a point along the LOS vector where intersection testing will end.</p>   |
| <p>Source Altitude: Double IEEE : meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: N/A</p> <p>Datum: Mean Sea Level (see Figure 6)</p> | <p>This parameter specifies the altitude of the source point of the LOS request vector.</p>  |

|   |  |
|---|--|
| <p>Source Latitude: Double IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +90 (north positive)<br/>0 to -90 (south negative)</p> <p>Default: N/A<br/>Datum: Equator (see Figure 6)</p>         | <p>This parameter specifies the latitudinal position of the source point of the LOS request vector.</p>  |
| <p>Source Longitude: Double IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +180 (east positive)<br/>0 to -180 (west negative)</p> <p>Default: N/A<br/>Datum: Prime Meridian (see Figure 6)</p> | <p>This parameter specifies the longitudinal position of the source point of the LOS request vector.</p> |

### 5.3.18 Height of Terrain Request

The Height of Terrain Request data packet is contained in the Ethernet message sent from the Host to the IG. It is used to request the height of terrain (HOT) at a specified location. If HOT is required for an entity, the host should insert the positional information for that entity in this data packet. To match up requests from the host with responses from the IG, the HOT ID parameter is used. The same value will be returned in the HOT ID parameter of the corresponding Height of Terrain Response data packet, described in section 5.4.6, to uniquely identify the response. The HOT ID value should be manipulated in such a way as to not duplicate the value in a reasonable amount of time (e.g., one second). This will prevent similarly identified requests from being lost by the IG.

There is no restriction on the number of HOT requests that can be sent in a single frame. The user should be aware, however, that the response time of the IG might be degraded under conditions that overload the IG HOT computation mechanism.

The IG will only return valid HOT data for points within the bounds of the database being displayed. If a point beyond the database bounds is requested, an invalid response will be returned in the Height of Terrain Response data packet. Refer to the applicable Database and Entity Attribute Definition Document(s) for details on the extent of the database.

The contents of the Height of Terrain Request data packet are shown below.

| 31             | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15              | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|----------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|-----------------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| Packet ID = 44 |    |    |    |    |    |    |    | Packet Size = 24 bytes |    |    |    |    |    |    |    | HOT ID          |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Spare          |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |                 |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Latitude (MSW)  |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Latitude (LSW)  |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Longitude (MSW) |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Longitude (LSW) |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

Height of Terrain Point Request Parameter Definitions:

| Formats and Ranges   | Description  |
|--|--|
| Packet ID = 44 : unsigned char : N/A   | This parameter identifies this data packet as a Height of Terrain Request data packet.<br><br>There can be multiple instances of this data packet per frame, but each unique HOT request should only be specified once per frame. If more than one data packet with the same HOT ID is received in the same frame, the last one received will be used. |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.  |
| HOT ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A | This parameter is used to identify the HOT request so that when the response to the request is returned it can be identified by the host. This is done via the HOT ID parameter of the Height of Terrain Response data packet.   |

|                                   |  |
|-----------------------------------|--|
| Latitude : Double IEEE : degrees  | This parameter specifies the latitudinal position from which the HOT request is made.  |
| Valid Values:                     |  |
| 0 to +90 (north positive)         |  |
| 0 to -90 (south negative)         |  |
| Default: N/A                      |  |
| Datum: Equator                    |  |
| Longitude : Double IEEE : degrees | This parameter specifies the longitudinal position from which the HOT request is made. |
| Valid Values:                     |  |
| 0 to +180 (east positive)         |  |
| 0 to -180 (west negative)         |  |
| Default: N/A                      |  |
| Datum: Prime Meridian             |  |

**5.4 IG-to-Host Packets**

**5.4.1 Start of Frame**

The Start of Frame data packet is the first packet contained in the Ethernet message sent from the IG to the Host. When the Host receives the Start of Frame data packet, it should respond immediately with the Host to IG Ethernet message containing all mandatory data packets and any other data packets necessary to describe data changes to the IG.

The contents of the Start of Frame data packet are shown below.

|                          |    |    |    |    |    |    |    |                        |    |       |    |    |    |    |    |                         |    |    |    |    |    |   |   |                 |   |   |   |   |   |   |   |
|--------------------------|----|----|----|----|----|----|----|------------------------|----|-------|----|----|----|----|----|-------------------------|----|----|----|----|----|---|---|-----------------|---|---|---|---|---|---|---|
| 31                       | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21    | 20 | 19 | 18 | 17 | 16 | 15                      | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7               | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 101          |    |    |    |    |    |    |    | Packet Size = 16 bytes |    |       |    |    |    |    |    | CIGI version number = 2 |    |    |    |    |    |   |   | Database Number |   |   |   |   |   |   |   |
| IG Status Code           |    |    |    |    |    |    |    | *1                     |    | Spare |    |    |    |    |    |                         |    |    |    |    |    |   |   |                 |   |   |   |   |   |   |   |
| IG to Host Frame Counter |    |    |    |    |    |    |    |                        |    |       |    |    |    |    |    |                         |    |    |    |    |    |   |   |                 |   |   |   |   |   |   |   |
| Timing Value             |    |    |    |    |    |    |    |                        |    |       |    |    |    |    |    |                         |    |    |    |    |    |   |   |                 |   |   |   |   |   |   |   |

\*1 Current IG Mode

Start of Frame Parameter Definitions:

| Formats and Ranges  | Description  |
|---|--|
| Packet ID = 101 : unsigned char : N/A   | This parameter identifies this data packet as the Start of Frame data packet.<br><br>There will be only one instance of this data packet per frame.  |
| Packet Size : unsigned char : N/A   | This parameter indicates the number of bytes in this data packet.  |
| CIGI version number : unsigned char : N/A<br><br>Valid Values:<br><br>0 – 255<br><br>Default: N/A   | This parameter indicates the version of the CIGI interface that is currently running on the image generator. The host can use this number to determine concurrency.  |
| Database Number : signed char : N/A<br><br>Valid Values:<br>–128 The requested database is not available<br>–127 to –1 The requested database is being loaded<br>0 No database is loaded or being loaded<br>+1 to +127 The designated database is loaded<br><br>See the Database Number table in the applicable Database and Entity Attribute Definition Document(s).<br><br>Default: N/A | This parameter indicates load status of the requested database.<br><br>The IG will return a value of –128 while the Host is requesting a database that is not available.<br><br>See the Database Number parameter of the IG Control data packet, described in section 5.3 for a further discussion on database loading theory. |
| IG Status Code : unsigned char : N/A<br><br>Valid Values:<br><br>0 – normal operation<br>1 – 255 See assignments in Table 5.<br><br>Default: 0  | This parameter indicates the operational status of the IG.   |



Current IG Mode : 2 bit field : N/A

Valid Values:

- 0 = Standby/Reset
- 1 = Operate
- 2 = Debug
- 3 = Off-Line Maintenance

Default: 0

This parameter identifies to the Host the current operating mode of the IG. When the IG receives a request for a mode change via the IG Mode Change Request parameter of the IG Control data packet, it will return the corresponding mode in this parameter once the mode change has been accomplished.

*Standby/Reset* – This is the mode to which the IG will be initialized during start up. In this mode, the IG will initialize the mission scenario to begin a new mission. All entities that were instantiated during a previous mission will be removed from the display. While in this mode, the IG will only send the Start of Frame data packet to the Host and will ignore Host inputs except for the IG Mode parameter of the IG Control data packet. Also during this mode, the IG may be put into maintenance mode via a graphical user interface provided on the IG.

*Operate* – In this mode, the IG will accept all data packet types destined for the IG. The IG will also return all data packet types appropriate for real-time operation. While in this mode, the IG will report errors to the Host via the IG Status Code parameter of this data packet. Because of the real-time nature of this mode, status codes are provided only for informational purposes. If further investigation is necessary, the debug mode should be used for non-real-time operation.

*Debug* – In this mode, the IG will accept all data packet types destined for the IG. The IG will also return all data packet types appropriate for real-time operation. This mode can be used as a diagnostic tool while integrating or troubleshooting the Host and IG interface. Because of error logging that takes place during this mode the IG may not always operate in a real-time fashion. While in this mode, the IG will report errors to the Host via the Image Generator Message data packet. Also, a log of all status messages is kept on the IG. Typically, status logs are regenerated each time the CIGI is started. However, log archives can be saved for later diagnosis.

*Off-line maintenance* – The off-line maintenance mode can be activated only from the IG. While the IG is in this mode, the Host cannot change the IG mode. The IG must initiate a mode change to Standby/Reset before the Host can command a mode change. While in the off-line maintenance mode the IG will only send the Start of Frame data packet to the Host and will ignore all Host commands.

When the IG transitions from a mode where it has ignored Host commands, the Host must initialize the IG to the proper mission scenario start conditions.

|   |  |
|---|--|
| IG to Host Frame Counter : unsigned integer : N/A | This parameter contains a number representing a particular frame. This number is incremented each frame by the IG. It is intended to be used in conjunction with the Host to IG Frame Counter parameter in the IG Control data packet to assist in correlating IG and Host frames.   |
| Valid Values:                                     | When this parameter reaches its maximum value, it will roll back to zero.  |
| 0 to 4,294,967,295                                |  |
| Default: N/A                                      |  |
| Timing Value : Float IEEE: $\mu$ sec              | The use of this parameter is optional for synchronous operation, but required for asynchronous operation. It contains a timing value that is used to time-tag the Ethernet message during asynchronous operation. When asynchronous operation is used, the synchronous timing scheme described in section 2.1.1 is superceded. |
| Valid Values:                                     | In order to preserve floating-point accuracy, this timing value is limited to a 24-hour simulation period. At the end of 24 hours, the counter will reset to zero.   |
| 0 to 86,399,999,999.99                            |  |
| Default: N/A                                      |  |

**5.4.2 Height Above Terrain Response**

The Height Above Terrain Response data packet is contained in the Ethernet message sent from the IG to the Host. It is used to respond to a Height Above Terrain Request. To match up requests from the host with responses from the IG, the HAT ID parameter is used. The value of this field is the same as that used in the HAT ID in the Height Above Terrain Request data packet used to make the original request. See the Height Above Terrain Request data packet narrative in section 5.3.15 for more information on this correlation scheme.

The contents of the Height Above Terrain Response data packet are shown below.

|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |                |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|-----------------|-------|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|--------|----------------|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31              | 30    | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15     | 14             | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 102 |       |    |    |    |    |    |    | Packet Size = 24 bytes |    |    |    |    |    |    |    | HAT ID |                |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| *1              | Spare |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |                |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        | Spare          |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        | Material Type  |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        | Altitude (MSW) |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        | Altitude (LSW) |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

\*1 Valid

Height Above Terrain Response Parameter Definitions:

| Formats and Ranges   | Description  |
|--|--|
| Packet ID = 102 : unsigned char : N/A  | This parameter identifies this data packet as a Height Above Terrain Response data packet.<br><br>There can be multiple instances of this data packet per frame. Each instance is uniquely identified by the HAT ID parameter. |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.  |
| HAT ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A   | This parameter identifies the HAT response corresponding to the associated HAT request. This parameter is provided to allow the host to match this response with the issued request.   |
| Valid : Boolean : N/A<br><br>Valid Values:<br><br>0 = invalid<br>1 = valid<br><br>Default: N/A   | This parameter is used to indicate whether the response is valid or invalid. A response is invalid if the test point was located beyond the bounds of the database.  |
| Material Type : integer : N/A<br><br>Valid Values:<br><br>See the Material type assignments in the applicable Database and Entity Attribute Definition Document (s).<br><br>Default: N/A | This parameter specifies the Material Type of the object intersected by the HAT test vector.   |

Altitude: Double IEEE : meters

This parameter represents the altitude above or below the terrain for the position requested in the Height Above Terrain Request data packet.

Valid Values:

Minimum to maximum allowed by the data format

Default: N/A

**5.4.3 Line of Sight Response**

The Line of Sight Response data packet is contained in the Ethernet message sent from the IG to the Host. It is used to respond to both Line of Sight Occult Request and Line of Sight Range Request packets. To match up requests from the host with responses from the IG the LOS ID parameter is used. The value of this field is the same as that used in the LOS ID parameter in either the Line of Sight Occult Request or the Line of Sight Range Request data packet used to make the original request. See the Line of Sight Occult Request or the Line of Sight Range Request data packet’s narrative for more information on this correlation scheme in sections 5.3.16 and 5.3.17.

The contents of the Line of Sight Response data packet are shown below.

|                              |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|------------------------------|----|-------|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|--------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31                           | 30 | 29    | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15     | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 103              |    |       |    |    |    |    |    | Packet Size = 40 bytes |    |    |    |    |    |    |    | LOS ID |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| *1                           | *2 | Spare |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Material Type                |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Range                        |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Intersection Altitude (MSW)  |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Intersection Altitude (LSW)  |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Intersection Latitude (MSW)  |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Intersection Latitude (LSW)  |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Intersection Longitude (MSW) |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Intersection Longitude (LSW) |    |       |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

\*1 Valid

\*2 Occult Response

Line of Sight Response Parameter Definitions:

| Formats and Ranges   | Description   |
|--|---|
| Packet ID = 103 : unsigned char : N/A  | This parameter identifies this data packet as a Line of Sight Response data packet.<br><br>There can be multiple instances of this data packet per frame. Each instance is uniquely identified by the LOS ID parameter. |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.   |
| LOS ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A       | This parameter identifies the LOS response corresponding to the associated LOS request. This parameter is provided to allow the host to match this response with the issued request.                                    |
| Valid : Boolean : N/A<br><br>Valid Values:<br><br>0 = invalid<br>1 = valid<br><br>Default: N/A | This parameter is used to indicate whether the response is valid or invalid. A response is invalid if the LOS test segment does not intersect with any geometry.  |

|   |  |
|---|--|
| <p>Occult Response : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = occulted<br/>1 = visible</p> <p>Default: N/A</p>   | <p>This parameter is used to respond to the LOS Occult Request data packet. It indicates whether the destination point is visible from the source point.</p> <p>This field is not applicable to the LOS Range Request data packet.</p>   |
| <p>Material Type : integer : N/A</p> <p>Valid Values:</p> <p>See the Material type assignments in the applicable Database and Entity Attribute Definition Document (s).</p> <p>Default: N/A</p>           | <p>This parameter specifies the Material Type of the object intersected by the LOS test segment.</p>   |
| <p>Range: Float IEEE : meters</p> <p>Valid Values:</p> <p>-1 = beyond requested LOS Maximum Range<br/>0 to maximum allowed by the data format</p> <p>Default: N/A</p>                                     | <p>This parameter is used to respond to the Line of Sight Range Request data packet.</p> <p>If an object is not intersected within the active LOS segment, that is, between the minimum and maximum distances as specified in the Line of Sight Range Request data packet, the Response Validity will indicate a valid response and the LOS Range Response will contain a negative one (-1). Otherwise, the LOS Range Response will contain the range of the intersection from the source position specified in the Line of Sight Range Request data packet.</p> |
| <p>Intersection Altitude : Double IEEE : meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format</p> <p>Default: N/A</p> <p>Datum: Mean Sea Level, see Figure 6.</p>             | <p>This parameter specifies the altitude of the point of intersection of the LOS request vector with an object.</p> <p>If the LOS Range Response in this data packet contains a negative one (-1) this altitude value should be ignored.</p>   |
| <p>Intersection Latitude : Double IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +90 (north positive)<br/>0 to -90 (south negative)</p> <p>Default: N/A</p> <p>Datum: equator, see Figure 6.</p>         | <p>This parameter specifies the latitudinal position of the intersection point of the LOS request vector with an object.</p> <p>If the LOS Range Response in this data packet contains a negative one (-1) this latitude value should be ignored.</p>  |
| <p>Intersection Longitude : Double IEEE : degrees</p> <p>Valid Values:</p> <p>0 to +180 (east positive)<br/>0 to -180 (west negative)</p> <p>Default: N/A</p> <p>Datum: Prime Meridian, see Figure 6.</p> | <p>This parameter specifies the longitudinal position of the intersection point of the LOS request vector with an object.</p> <p>If the LOS Range Response in this data packet contains a negative one (-1) this longitude value should be ignored.</p>  |

#### 5.4.4 Collision Detection Segment Response

The Collision Detection Segment Response data packet is contained in the Ethernet message sent from the IG to the Host. There can be up to 127 locations of contact specified on an entity. These are uniquely identified using the segment ID parameter.

The Collision Detection Segment Response data packet will be returned if the following three conditions are met: a collision occurs, the Segment Enable parameter in the Collision Detection Segment Definition data packet is enabled, and the Collision Detection Request parameter in the Entity Control data packet is enabled. Explanations of these parameters can be found in their respective sections in this document.

If two entities contact each other, then a Collision Detection Segment Response data packet would be generated for each entity provided that collision detection is enabled for both. If collision detection is disabled for either entity, then no Collision Detection Segment Response packet will be sent.

The contents of the Collision Detection Segment Response data packet are shown below.

| 31              | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16                  | 15                | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-----------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|---------------------|-------------------|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| Packet ID = 104 |    |    |    |    |    |    |    | Packet Size = 24 bytes |    |    |    |    |    |    |                     | Entity ID         |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| Segment ID      |    |    |    |    |    |    | *1 | Spare                  |    |    |    |    |    |    | Contacted Entity ID |                   |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |                     | Material Type     |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |                     | Collision Point X |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |                     | Collision Point Y |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |                     | Collision Point Z |    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

\*1 Entity/Non-Entity Contact

Collision Detection Segment Response Parameter Definitions:


| Formats and Ranges  | Description  |
|---|--|
| Packet ID = 104 : unsigned char : N/A   | This parameter identifies this data packet as a Collision Detection Segment Response data packet.<br><br>There can be multiple instances of this data packet per frame. Each instance is uniquely identified by the Entity ID and Segment ID parameters. |
| Packet Size : unsigned char : N/A   | This parameter indicates the number of bytes in this data packet.  |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A | This parameter indicates which entity experienced a collision.   |
| Segment ID : 7 bit field : N/A<br><br>Valid Values:<br><br>0 to 127<br><br>Default: N/A     | This parameter identifies the collision segment. This parameter is provided to allow the host to match this response with the proper segment.  |

|   |   |
|---|---|
| <p>Entity/Non-Entity Contact : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = contact with non entity surface<br/>1 = contact with a defined entity</p> <p>Default: N/A</p>  | <p>The parameter indicates whether another entity was contacted during this collision. If this parameter indicates contact with non-entity surface (0), then the Contacted Entity ID field is ignored. If this parameter indicates contact with a defined entity (1), then the Contacted Entity ID field shall contain the Entity ID of the entity that was contacted.</p>    |
| <p>Contacted Entity ID : unsigned short : N/A</p> <p>Valid Values:</p> <p>0 to 65535</p> <p>Default: N/A</p>  | <p>This parameter indicates which entity was contacted during the collision.</p> <p>If the Entity/Non-Entity Contact parameter of this data packet indicates contact with non-entity surface (0), then this field is ignored. If the parameter indicates contact with a defined entity (1), then this field shall contain the Entity ID of the entity that was contacted.</p> |
| <p>Material Type: integer : N/A</p> <p>Valid Values:</p> <p>See the Material type assignments in the applicable Database and Entity Attribute Definition Document (s).</p> <p>Default: N/A</p>  | <p>This parameter specifies the Material Type of the surface that this collision test segment contacted.</p>  |
| <p>Collision Point X: Float IEEE: meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format limited to the extent of the segment</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the X component of a vector, which lies along the defined segment where the segment intersected a surface. When fully defined by the X, Y, and Z, collision vector components the collision point will lie upon the originally defined segment. This vector will originate from the source location of the Collision Detection Segment.</p>       |
| <p>Collision Point Y: Float IEEE: meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format limited to the extent of the segment</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the Y component of a vector, which lies along the defined segment where the segment intersected a surface. When fully defined by the X, Y, and Z, collision vector components the collision point will lie upon the originally defined segment. This vector will originate from the source location of the Collision Detection Segment.</p>       |
| <p>Collision Point Z: Float IEEE: meters</p> <p>Valid Values:</p> <p>Minimum to maximum allowed by the data format limited to the extent of the segment</p> <p>Default: N/A</p> <p>Datum: Entity coordinate system, see Figure 9.</p> | <p>This parameter specifies the Z component of a vector, which lies along the defined segment where the segment intersected a surface. When fully defined by the X, Y, and Z, collision vector components the collision point will lie upon the originally defined segment. This vector will originate from the source location of the Collision Detection Segment.</p>       |



**5.4.5 Sensor Response**

The Sensor Response data packet is contained in the Ethernet message sent from the IG to the Host. It is used to report aspects of the Sensor tracker to the Host. For every frame that the sensor specified by the Sensor ID is active, this packet must be returned to the host. Otherwise information will be lost to the Host.



The X-Y coordinate system is oriented such that +X is to the right and +Y is up. Its origin is at the intersection of the view plane normal and the view plane.

**Figure 30 – Gate Offset and Size**

The contents of the Sensor Response data packet are shown below.

|                 |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |                 |    |    |    |    |    |           |   |   |   |   |   |   |   |   |   |
|-----------------|----|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|-----------------|----|----|----|----|----|-----------|---|---|---|---|---|---|---|---|---|
| 31              | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15              | 14 | 13 | 12 | 11 | 10 | 9         | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 105 |    |    |    |    |    |    |    | Packet Size = 12 bytes |    |    |    |    |    |    |    | View ID         |    |    |    | *1 | S  | Sensor ID |   |   |   |   |   |   |   |   |   |
| Target X Offset |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Target Y Offset |    |    |    |    |    |           |   |   |   |   |   |   |   |   |   |
| Gate X Size     |    |    |    |    |    |    |    |                        |    |    |    |    |    |    |    | Gate Y Size     |    |    |    |    |    |           |   |   |   |   |   |   |   |   |   |

\*1 Sensor Status

Sensor Response Parameter Definitions:

| Formats and Ranges                    | Description  |
|---------------------------------------|--|
| Packet ID = 105 : unsigned char : N/A | This parameter identifies this data packet as Sensor Response data packet.<br><br>There will be one of these data packets for each active Sensor view. |
| Packet Size : unsigned char : N/A     | This parameter indicates the number of bytes in this data packet.  |

|  |  |
|--|--|
| <p>View ID: 5 bit field : N/A</p> <p>valid value:</p> <p>0 – 31</p> <p>Default N/A</p>   | <p>This parameter indicates the Sensor view to which this data packet is applicable.</p>   |
| <p>Sensor Status : 2 bit field : N/A</p> <p>Valid Values:</p> <p>0 = Searching for Target<br/>1 = Tracking<br/>2 = Impending Breaklock<br/>3 = Breaklock</p> <p>Default: N/A</p>             | <p>This parameter indicates the current Sensor mode.</p>   |
| <p>Sensor ID : unsigned char : N/A</p> <p>Valid Values:</p> <p>0 to 255</p> <p>Default: N/A</p>  | <p>This parameter identifies the Sensor response corresponding to the associated Sensor Control data packet. This parameter is provided to allow the host to match this response with the issued Sensor Control data packet and its associated data packets.</p> |
| <p>Gate X Offset: angle format (16 bit): degrees</p> <p>Valid Values:</p> <p>Positive and negative values bounded by the specified view</p> <p>Default: N/A</p> <p>Datum: see Figure 30.</p> | <p>This parameter specifies the target's horizontal offset from the view plane normal.</p>   |
| <p>Gate Y Offset: angle format (16 bit): degrees</p> <p>Valid Values:</p> <p>Positive and negative values bounded by the specified view</p> <p>Default: N/A</p> <p>Datum: see Figure 30.</p> | <p>This parameter specifies the target's vertical offset from the view plane normal.</p>   |
| <p>Gate X Size: unsigned short : See note to right</p> <p>Valid Values:</p> <p>0 to maximum required</p> <p>Default: N/A</p> <p>Datum: see Figure 30.</p>                                    | <p>This parameter specifies the target size in the X direction (horizontal) in pixels.</p> <p>Note: The units can be either pixels or lines depending on the view rotation.</p>  |

Gate Y Size: unsigned short : See note to right

This parameter specifies the target size in the Y direction (vertical) in pixels.

Valid Values:

0 to maximum required

Note: The units can be either pixels or lines depending on the view rotation.

Default: N/A

Datum: see Figure 30.

### 5.4.6 Height of Terrain Response

The Height of Terrain Response data packet is contained in the Ethernet message sent from the IG to the Host. It is used to respond to a Height of Terrain Request. To match up requests from the host with responses from the IG the HOT ID parameter is used. The value is the same as that used in the HOT ID in the Height of Terrain Request data packet used to make the original request. See the Height of Terrain Request data packet narrative in section 5.3.18 for more information on this correlation scheme.

The contents of the Height of Terrain Response data packet are shown below.

|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |                |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|-----------------|-------|----|----|----|----|----|----|------------------------|----|----|----|----|----|----|----|--------|----------------|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 31              | 30    | 29 | 28 | 27 | 26 | 25 | 24 | 23                     | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15     | 14             | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Packet ID = 106 |       |    |    |    |    |    |    | Packet Size = 24 bytes |    |    |    |    |    |    |    | HOT ID |                |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
| *1              | Spare |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        |                |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        | Spare          |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        | Material Type  |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        | Altitude (MSW) |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|                 |       |    |    |    |    |    |    |                        |    |    |    |    |    |    |    |        | Altitude (LSW) |    |    |    |    |   |   |   |   |   |   |   |   |   |   |

\*1 Valid

Height of Terrain Response Parameter Definitions:

| Formats and Ranges   | Description   |
|--|---|
| Packet ID = 106 : unsigned char : N/A  | This parameter identifies this data packet as a Height of Terrain Response data packet.<br><br>There can be multiple instances of this data packet per frame. Each instance is uniquely identified by the HOT ID parameter. |
| Packet Size : unsigned char : N/A  | This parameter indicates the number of bytes in this data packet.   |
| HOT ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A   | This parameter identifies the HOT response corresponding to the associated HOT request. This parameter is provided to allow the host to match this response with the issued request.  |
| Valid : Boolean : N/A<br><br>Valid Values:<br><br>0 = invalid<br>1 = valid<br><br>Default: N/A   | This parameter is used to indicate whether the response is valid or invalid. A response is invalid if the test point was located beyond the bounds of the database.   |
| Material Type : integer : N/A<br><br>Valid Values:<br><br>See the Material type assignments in the applicable Database and Entity Attribute Definition Document (s).<br><br>Default: N/A | This parameter specifies the Material Type of the object intersected by the HOT test segment.   |

Altitude: Double IEEE : meters

This parameter represents the altitude of the terrain for the position requested in the Height of Terrain Request data packet.

Valid Values:

Minimum to maximum allowed by the data format

Default: N/A

Datum: Mean Sea Level

### 5.4.7 Collision Detection Volume Response

The Collision Detection Volume Response data packet is contained in the Ethernet message sent from the IG to the Host. The Collision Detection Volume mechanism can be used when it is only important for the Host to know when two objects have made contact. This response does not contain contact location or material type information. There can be up to 127 impact volumes specified on an entity. These are uniquely identified using the volume ID parameter. This data packet will be returned if the following three conditions are met: a collision occurs, the enable parameter in the Collision Detection Volume Definition data packet is enabled, and the collision detection request switch in the Entity Control data packet is enabled. Explanations of these parameters can be found in their respective sections of this document.

If two entities contact each other, then a Collision Detection Volume Response data packet would be generated for each entity provided that collision detection is enabled for both. If collision detection is disabled for either entity, then no Collision Detection Volume Response packet will be sent.

The contents of the Collision Detection Volume Response data packet are shown below.

|                 |    |    |    |    |    |    |    |                       |       |    |    |    |    |    |    |           |                     |    |    |    |    |   |   |   |   |   |   |   |   |   |   |  |
|-----------------|----|----|----|----|----|----|----|-----------------------|-------|----|----|----|----|----|----|-----------|---------------------|----|----|----|----|---|---|---|---|---|---|---|---|---|---|--|
| 31              | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23                    | 22    | 21 | 20 | 19 | 18 | 17 | 16 | 15        | 14                  | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |  |
| Packet ID = 107 |    |    |    |    |    |    |    | Packet Size = 8 bytes |       |    |    |    |    |    |    | Entity ID |                     |    |    |    |    |   |   |   |   |   |   |   |   |   |   |  |
| Volume ID       |    |    |    |    |    |    |    | *1                    | Spare |    |    |    |    |    |    |           | Contacted Entity ID |    |    |    |    |   |   |   |   |   |   |   |   |   |   |  |

\*1 Entity/Non-Entity Contact

Collision Detection Volume Response Parameter Definitions:

| Formats and Ranges  | Description   |
|---|---|
| Packet ID = 107 : unsigned char : N/A   | This parameter identifies this data packet as a Collision Detection Volume Response data packet.<br><br>There can be multiple instances of this data packet per frame. The Volume ID and Entity ID parameters will uniquely identify each instance. |
| Packet Size : unsigned char : N/A   | This parameter indicates the number of bytes in this data packet.   |
| Entity ID : unsigned short : N/A<br><br>Valid Values:<br><br>0 to 65535<br><br>Default: N/A | This parameter indicates which entity experienced a collision.  |
| Volume ID : 7 bit field : N/A<br><br>Valid Values:<br><br>0 to 127<br><br>Default: N/A      | This parameter identifies the collision volume corresponding to the associated Collision Detection Volume Request. This parameter is provided to allow the host to match this response with the issued request.                                     |

|  |  |
|--|--|
| <p>Entity/Non-Entity Contact : Boolean : N/A</p> <p>Valid Values:</p> <p>0 = contact with non entity surface<br/>1 = contact with a defined entity</p> <p>Default: N/A</p> | <p>The parameter indicates whether another entity was contacted during this collision. If this parameter indicates contact with non-entity surface (0), then the Contacted Entity ID field is ignored. If this parameter indicates contact with a defined entity (1), then the Contacted Entity ID field shall contain the Entity ID of the entity that was contacted.</p>       |
| <p>Contacted Entity ID : unsigned short : N/A</p> <p>Valid Values:</p> <p>0 to 65535</p> <p>Default: N/A</p>   | <p>This parameter indicates which entity was contacted with during the collision.</p> <p>If the Entity/Non-Entity Contact switch of this data packet indicates contact with non-entity surface (0), then this field is ignored. If this parameter indicates contact with a defined entity (1), then this field shall contain the Entity ID of the entity that was contacted.</p> |





**5.5 User-Defined Data Packets**

A User-Defined data packet can be contained in the Ethernet message sent from either the Host to the IG or the IG to the Host. User-Defined data packets are provided as a custom packet mechanism to allow transmission of data not specifically supported by an existing CIGI packet.

When user-defined data packets are introduced into a particular CIGI application, they should adhere to the standard data packet format in order to maintain continuity across data packets. Standard data packet format includes the Packet ID in the first byte and the Packet Size in the second byte of the data packet. It is recommended that if data such as Entity ID and View ID are used in the data packet, these values be positioned and sized in similar fashion as other instances of like information within the interface. The Component Control data packet described in section 5.3.3 is a good example of this data formatting.


The size of each user-defined data packet depends on the amount of data contained in the packet. The programmer should place the total number of bytes, including the two bytes of header, in the Packet Size field of this packet so that the Host can accept the packet properly.

It must be understood that when a user-defined data packet is introduced into a particular implementation of the CIGI, that implementation will no longer conform to the baseline packet definitions within CIGI and hence may not be acceptable to the general CIGI user community.

It is also important to note that an attempt has been made to contain information within a CIGI data packet that is consistent with what might be expected in a real-world object. Even though it may be convenient under some circumstances to place information into a data packet that is not pertinent or realistic to the data packet’s intent, this is not recommended. The intent of the CIGI in this respect is to provide an object-oriented interface that can be used for an entire spectrum of applications. When unrealistic information or functionality is contained in the interface, it makes it more difficult to apply in an abstract sense.

To remain consistent with the CIGI, any user-defined fields should use big -endian byte ordering.

The contents of the User Definable data packet are shown below.



User Definable Parameter Definitions:

| Formats and Ranges                           | Description  |
|--|--|
| Packet ID = 236 to 255 : unsigned char : N/A | This parameter identifies this data packet as a User-Defined data packet.<br><br>There may or may not be multiple instances of this data packet per frame depending on its intended use. |
| Packet Size : unsigned char : N/A            | This parameter indicates the number of bytes in this data packet.  |

User Definable Data : formatted as needed

Valid Values:

user defined

Default: N/A

The remainder of the fields in this data packet are user-defined. The data may be made up of Booleans, chars, integer shorts, integer longs, floats, and doubles as needed.

## 6. Status Messages

Following is a table of suggested status message definitions that may be reported from the CIGI to the Host in the IG Status parameter of the Start of Frame data packet described in section 5.4. Because this parameter can only hold one IG Status Number at a time if two or more messages are generated in the same frame an IG Status Number of 24 will be generated to indicate that multiple errors exist.

**Table 5 – CIGI status messages**

| IG Status Number | Error Description  |
|------------------|--|
| 0                | Normal Operation   |
| 1                | The IG Control data packet was not the first data packet detected in the Host-to-CIGI message. |
| 2                | Invalid Entity Type in Entity Control data packet.   |
| 3                | An Entity Control data packet contains an inactive Parent Entity ID.                           |
| 4                | A Component Control data packet contains an inactive Entity ID.                                |
| 5                | A Component Control data packet contains an invalid Component ID.                              |
| 6                | A Component Control data packet contains an invalid Component State.                           |
| 7                | A Component Control data packet contains an invalid Component Value.                           |
| 8                | An Articulated Part Control data packet contains an invalid Articulated Part ID.               |
| 9                | An Articulated Part Control data packet contains an inactive Entity ID.                        |
| 10               | A Rate Control data packet contains an inactive Entity ID.                                     |
| 11               | A Rate Control data packet contains an invalid Articulated Part ID.                            |
| 12               | An Environment Control data packet contains values are outside the specified range.            |
| 13               | A View Control data packet contains an undefined view group.                                   |
| 14               | A View Control data packet contains an undefined view.   |
| 15               | A Sensor Control data packet contains an invalid value for Scene/Target track mode on/off.     |
| 16               | A Trajectory Definition data packet contains an inactive Entity ID.                            |
| 17               | A Special Effects Definition data packet contains an inactive Entity ID.                       |
| 18               | A View Definition data packet contains an undefined view.                                      |
| 19               | A View Definition data packet specified the Field of View Left value greater than the right.   |
| 20               | A View Definition data packet specified the Field of View Right value less than the left.      |
| 21               | A View Definition data packet specified the Field of View Top value less than the bottom.      |
| 22               | A View Definition data packet specified the Field of View Bottom value greater than the top.   |
| 23               | A Collision Detection Definition data packet contains an inactive Entity ID.                   |
| 24               | More than one status error has been generated in one frame.                                    |

## 7. Acronyms

|      |  |
|------|--|
| HAT  | Height Above Terrain                             |
| HOT  | Height of Terrain                                |
| Hz   | Hertz  |
| I/O  | Input/Output                                     |
| ICD  | Interface Control Document                       |
| ID   | Identification                                   |
| IG   | Image Generator                                  |
| IP   | Internet Protocol                                |
| IEEE | Institute of Electrical and Electronic Engineers |
| LOS  | Line-of-Sight                                    |
| LSW  | Least Significant Word                           |
| ms   | Millisecond(s)                                   |
| MSW  | Most Significant Word                            |
| N/A  | Not Applicable                                   |
| SOF  | Start of Frame                                   |
| TBD  | To Be Determined                                 |
| TCP  | Transfer Control Protocol                        |
| UDP  | User Datagram Protocol                           |